SUN2000-(20KTL, 29.9KTL, 30KTL, 36KTL, 40KTL)-M3

User Manual

Issue 17

Date 2024-02-02





Copyright © Huawei Technologies Co., Ltd. 2024. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks and Permissions

HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base

Bantian, Longgang Shenzhen 518129

People's Republic of China

Website: https://e.huawei.com

About This Document

Overview

This document describes the SUN2000-20KTL-M3, SUN2000-29.9KTL-M3, SUN2000-30KTL-M3, SUN2000-36KTL-M3, and SUN2000-40KTL-M3 (also referred to as SUN2000) in terms of their installation, electrical connections, commissioning, maintenance, and troubleshooting. Before installing and operating the SUN2000, ensure that you are familiar with the features, functions, and safety precautions provided in this document.

Intended Audience

This document is applicable to:

- Installers
- Users

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description	
<u></u>	Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.	
⚠ WARNING	Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.	
⚠ CAUTION	Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.	
NOTICE	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results.	
	NOTICE is used to address practices not related to personal injury.	

Symbol	Description
□ NOTE	Supplements the important information in the main text. NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.

Change History

Changes between document issues are cumulative. The latest document issue contains all changes made in earlier issues.

Issue 17 (2024-02-02)

Updated 10 Technical Specifications.

Issue 16 (2024-01-12)

Updated **2.2 Appearance**.

Updated 3 SUN2000 Storage.

Updated 4.4 Moving the SUN2000.

Updated 5.1 Precautions.

Updated **5.2 Preparing Cables**.

Updated 5.4 Connecting the AC Output Power Cable.

Updated 5.5.1 Cable Connection Description.

Updated 8.3 Alarm Reference.

Updated 10 Technical Specifications.

Updated A Grid Codes.

Updated L Contact Information.

Added M Digital Power Customer Service.

Issue 15 (2023-11-08)

Updated 4.3 Selecting an Installation Position.

Updated 5.7.1 Communication Modes.

Updated 7 Man-Machine Interaction.

Updated 10 Technical Specifications.

Issue 14 (2023-09-20)

Updated 5.5.1 Cable Connection Description.

Issue 13 (2023-04-28)

Updated A Grid Codes.

Added K Locating Insulation Resistance Faults.

Updated L Contact Information.

Issue 12 (2023-02-28)

Updated 2.1 Product Introduction.

Updated 5.2 Preparing Cables.

Updated 5.6 (Optional) Installing the Smart Dongle.

Updated 10 Technical Specifications.

Issue 11 (2023-01-10)

Updated 1 Safety Information.

Updated 2.3 Label Description.

Updated 4.2 Tool Preparation.

Updated 7 Man-Machine Interaction.

Updated 8.3 Alarm Reference.

Updated 10 Technical Specifications.

Added L Contact Information.

Issue 10 (2022-09-26)

Updated 5.2 Preparing Cables.

Updated 5.4 Connecting the AC Output Power Cable.

Issue 09 (2022-06-30)

Updated **5.2 Preparing Cables**.

Updated 5.5 Installing the DC Input Power Cable.

Updated 5.7.1 Communication Modes.

Updated 7 Man-Machine Interaction.

Updated 7.1.3 SmartLogger Networking Scenario.

Updated 8.3 Alarm Reference.

Updated 10 Technical Specifications.

Added I PV String Access Detection.

Issue 08 (2022-04-14)

Updated 5.2 Preparing Cables.

Updated 5.7.1 Communication Modes.

Updated **D Rapid Shutdown**.

Issue 07 (2022-01-30)

Updated 4.3 Selecting an Installation Position.

Updated 8.2 Routine Maintenance.

Issue 06 (2022-01-04)

Updated **5.2 Preparing Cables**.

Updated 7.1.2 Creating a PV Plant and a User.

Updated 7.3.1 Grid-tied Point Control.

Updated 7.3.2 Apparent Power Control on the Inverter Output Side.

Updated 10 Technical Specifications.

Updated A Grid Codes.

Issue 05 (2021-11-25)

Updated 5.4 Connecting the AC Output Power Cable.

Issue 04 (2021-07-25)

Updated **5.2 Preparing Cables**.

Updated 10 Technical Specifications.

Issue 03 (2021-04-15)

Updated 2.1 Product Introduction.

Updated 5.2 Preparing Cables.

Updated 5.5 Installing the DC Input Power Cable.

Updated 10 Technical Specifications.

Issue 02 (2020-11-20)

Updated 2.3 Label Description.

Updated 4.3 Selecting an Installation Position.

Updated **5.2 Preparing Cables**.

Updated 5.7.1 Communication Modes.

Updated 10 Technical Specifications.

Issue 01 (2020-10-15)

This issue is the first official release.

Contents

ii
1
2
4
7
8
13
13
15
16
18
18
18
20
21
21
22
23
27
28
29
30
31
33
33
37
39
44
44
46

r Manual	Contents

5.5.3 Connecting Cables to Staubli MC4 Connectors	
5.6 (Optional) Installing the Smart Dongle	
5.7.1 Communication Modes	
5.7.2 (Optional) Connecting the RS485 Communications Cable to the SUN2000	
5.7.3 (Optional) Connecting the RS485 Communications Cable to the Power Meter	
5.7.4 (Optional) Connecting the Power Grid Scheduling Signal Cable	
5.7.5 (Optional) Connecting the Rapid Shutdown Signal Cable	59
6 Commissioning	60
6.1 Checking Before Power-On	60
6.2 System Power-On	61
7 Man-Machine Interaction	63
7.1 Scenario in Which SUN2000s Are Connected to the FusionSolar Smart PV Management System.	64
7.1.1 (Optional) Registering an Installer Account	
7.1.2 Creating a PV Plant and a User	
7.1.3 SmartLogger Networking Scenario	
7.2 Scenario in Which SUN2000s Are Connected to Other Management Systems	
7.3 Energy Control	
7.3.2 Apparent Power Control on the Inverter Output Side	
8 Maintenance	
8.1 System Power-Off	
8.2 Routine Maintenance	
8.3 Alarm Reference	
9 Handling the Inverter	76
9.1 Removing the SUN2000	
9.2 Packing the SUN2000	76
9.3 Disposing of the SUN2000	76
10 Technical Specifications	77
A Grid Codes	88
B Device Commissioning	101
C Built-in PID Recovery	104
D Rapid Shutdown	105
E NS Protection	106
F Resetting Password	
G Setting Dry Contact Scheduling Parameters	
H AFCI	

User Manual	Contents
I PV String Access Detection	111
J Smart I-V Curve Diagnosis	114
K Locating Insulation Resistance Faults	115
L Contact Information	119
M Digital Power Customer Service	121
N Acronyms and Abbreviations	122

1 Safety Information

Statement

Before transporting, storing, installing, operating, using, and/or maintaining the equipment, read this document, strictly follow the instructions provided herein, and follow all the safety instructions on the equipment and in this document. In this document, "equipment" refers to the products, software, components, spare parts, and/or services related to this document; "the Company" refers to the manufacturer (producer), seller, and/or service provider of the equipment; "you" refers to the entity that transports, stores, installs, operates, uses, and/or maintains the equipment.

The Danger, Warning, Caution, and Notice statements described in this document do not cover all the safety precautions. You also need to comply with relevant international, national, or regional standards and industry practices. The Company shall not be liable for any consequences that may arise due to violations of safety requirements or safety standards concerning the design, production, and usage of the equipment.

The equipment shall be used in an environment that meets the design specifications. Otherwise, the equipment may be faulty, malfunctioning, or damaged, which is not covered under the warranty. The Company shall not be liable for any property loss, personal injury, or even death caused thereby.

Comply with applicable laws, regulations, standards, and specifications during transportation, storage, installation, operation, use, and maintenance.

Do not perform reverse engineering, decompilation, disassembly, adaptation, implantation, or other derivative operations on the equipment software. Do not study the internal implementation logic of the equipment, obtain the source code of the equipment software, violate intellectual property rights, or disclose any of the performance test results of the equipment software.

The Company shall not be liable for any of the following circumstances or their consequences:

- The equipment is damaged due to force majeure such as earthquakes, floods, volcanic eruptions, debris flows, lightning strikes, fires, wars, armed conflicts, typhoons, hurricanes, tornadoes, and other extreme weather conditions.
- The equipment is operated beyond the conditions specified in this document.

- The equipment is installed or used in environments that do not comply with international, national, or regional standards.
- The equipment is installed or used by unqualified personnel.
- You fail to follow the operation instructions and safety precautions on the product and in the document.
- You remove or modify the product or modify the software code without authorization.
- You or a third party authorized by you cause the equipment damage during transportation.
- The equipment is damaged due to storage conditions that do not meet the requirements specified in the product document.
- You fail to prepare materials and tools that comply with local laws, regulations, and related standards.
- The equipment is damaged due to your or a third party's negligence, intentional breach, gross negligence, or improper operations, or other reasons not related to the Company.

1.1 Personal Safety

⚠ DANGER

Ensure that power is off during installation. Do not install or remove a cable with power on. Transient contact between the core of the cable and the conductor will generate electric arcs or sparks, which may cause a fire or personal injury.

⚠ DANGER

Non-standard and improper operations on the energized equipment may cause fire, electric shocks, or explosion, resulting in property damage, personal injury, or even death.

⚠ DANGER

Before operations, remove conductive objects such as watches, bracelets, bangles, rings, and necklaces to prevent electric shocks.


DANGER

During operations, use dedicated insulated tools to prevent electric shocks or short circuits. The dielectric withstanding voltage level must comply with local laws, regulations, standards, and specifications.

MARNING

During operations, wear personal protective equipment such as protective clothing, insulated shoes, goggles, safety helmets, and insulated gloves.

Figure 1-1 Personal protective equipment



General Requirements

- Do not stop protective devices. Pay attention to the warnings, cautions, and related precautionary measures in this document and on the equipment.
- If there is a likelihood of personal injury or equipment damage during operations, immediately stop, report the case to the supervisor, and take feasible protective measures.
- Do not power on the equipment before it is installed or confirmed by professionals.
- Do not touch the power supply equipment directly or with conductors such as damp objects. Before touching any conductor surface or terminal, measure the voltage at the contact point to ensure that there is no risk of electric shock.
- Do not touch operating equipment because the enclosure is hot.
- Do not touch a running fan with your hands, components, screws, tools, or boards. Otherwise, personal injury or equipment damage may occur.
- In the case of a fire, immediately leave the building or the equipment area and activate the fire alarm or call emergency services. Do not enter the affected building or equipment area under any circumstances.

Personnel Requirements

- Only professionals and trained personnel are allowed to operate the equipment.
 - Professionals: personnel who are familiar with the working principles and structure of the equipment, trained or experienced in equipment operations and are clear of the sources and degree of various potential hazards in equipment installation, operation, maintenance

- Trained personnel: personnel who are trained in technology and safety, have required experience, are aware of possible hazards on themselves in certain operations, and are able to take protective measures to minimize the hazards on themselves and other people
- Personnel who plan to install or maintain the equipment must receive adequate training, be able to correctly perform all operations, and understand all necessary safety precautions and local relevant standards.
- Only qualified professionals or trained personnel are allowed to install, operate, and maintain the equipment.
- Only qualified professionals are allowed to remove safety facilities and inspect the equipment.
- Personnel who will perform special tasks such as electrical operations, working at heights, and operations of special equipment must possess the required local qualifications.
- Only authorized professionals are allowed to replace the equipment or components (including software).
- Only personnel who need to work on the equipment are allowed to access the equipment.

1.2 Electrical Safety

DANGER

Before connecting cables, ensure that the equipment is intact. Otherwise, electric shocks or fire may occur.

DANGER

Non-standard and improper operations may result in fire or electric shocks.

DANGER

Prevent foreign matter from entering the equipment during operations. Otherwise, equipment damage, load power derating, power failure, or personal injury may occur.

↑ WARNING

For the equipment that needs to be grounded, install the ground cable first when installing the equipment and remove the ground cable last when removing the equipment.

MARNING


During the installation of PV strings and the SUN2000, the positive or negative terminals of PV strings may be short-circuited to ground if the power cables are not properly installed or routed. In this case, an AC or DC short circuit may occur and damage the SUN2000. The resulting device damage is not covered under any warranty.

A CAUTION

Do not route cables near the air intake or exhaust vents of the equipment.

General Requirements

- Follow the procedures described in the document for installation, operation, and maintenance. Do not reconstruct or alter the equipment, add components, or change the installation sequence without permission.
- Obtain approval from the national or local electric utility company before connecting the equipment to the grid.
- Observe the power plant safety regulations, such as the operation and work ticket mechanisms.
- Install temporary fences or warning ropes and hang "No Entry" signs around the operation area to keep unauthorized personnel away from the area.
- Before installing or removing power cables, turn off the switches of the equipment and its upstream and downstream switches.
- Before performing operations on the equipment, check that all tools meet the requirements and record the tools. After the operations are complete, collect all of the tools to prevent them from being left inside the equipment.
- Before installing power cables, check that cable labels are correct and cable terminals are insulated.
- When installing the equipment, use a torque tool of a proper measurement range to tighten the screws. When using a wrench to tighten the screws, ensure that the wrench does not tilt and the torque error does not exceed 10% of the specified value.
- Ensure that bolts are tightened with a torque tool and marked in red and blue after double-check. Installation personnel mark tightened bolts in blue.
 Quality inspection personnel confirm that the bolts are tightened and then mark them in red. (The marks must cross the edges of the bolts.)



- If the equipment has multiple inputs, disconnect all the inputs before operating the equipment.
- Before maintaining a downstream electrical or power distribution device, turn off the output switch on the power supply equipment.

- During equipment maintenance, attach "Do not switch on" labels near the upstream and downstream switches or circuit breakers as well as warning signs to prevent accidental connection. The equipment can be powered on only after troubleshooting is complete.
- Do not open equipment panels.
- Check equipment connections periodically, ensuring that all screws are securely tightened.
- Only qualified professionals can replace a damaged cable.
- Do not scrawl, damage, or block any labels or nameplates on the equipment. Promptly replace labels that have worn out.
- Do not use solvents such as water, alcohol, or oil to clean electrical components inside or outside of the equipment.

Grounding

- Ensure that the grounding impedance of the equipment complies with local electrical standards.
- Ensure that the equipment is connected permanently to the protective ground. Before operating the equipment, check its electrical connection to ensure that it is reliably grounded.
- Do not work on the equipment in the absence of a properly installed ground conductor.
- Do not damage the ground conductor.

Cabling Requirements

- When selecting, installing, and routing cables, follow local safety regulations and rules.
- When routing power cables, ensure that there is no coiling or twisting. Do not join or weld power cables. If necessary, use a longer cable.
- Ensure that all cables are properly connected and insulated, and meet specifications.
- Ensure that the slots and holes for routing cables are free from sharp edges, and that the positions where cables are routed through pipes or cable holes are equipped with cushion materials to prevent the cables from being damaged by sharp edges or burrs.
- Ensure that cables of the same type are bound together neatly and straight and that the cable sheath is intact. When routing cables of different types, ensure that they are away from each other without entanglement and overlapping.
- Secure buried cables using cable supports and cable clips. Ensure that the cables in the backfill area are in close contact with the ground to prevent cable deformation or damage during backfilling.
- If the external conditions (such as the cable layout or ambient temperature) change, verify the cable usage in accordance with the IEC-60364-5-52 or local laws and regulations. For example, check that the current-carrying capacity meets requirements.
- When routing cables, reserve at least 30 mm clearance between the cables and heat-generating components or areas. This prevents deterioration or damage to the cable insulation layer.

User Manual

1.3 Environment Requirements

DANGER

Do not expose the equipment to flammable or explosive gas or smoke. Do not perform any operation on the equipment in such environments.

M DANGER

Do not store any flammable or explosive materials in the equipment area.

M DANGER

Do not place the equipment near heat sources or fire sources, such as smoke, candles, heaters, or other heating devices. Overheat may damage the equipment or cause a fire.

№ WARNING

Install the equipment in an area far away from liquids. Do not install it under areas prone to condensation, such as under water pipes and air exhaust vents, or areas prone to water leakage, such as air conditioner vents, ventilation vents, or feeder windows of the equipment room. Ensure that no liquid enters the equipment to prevent faults or short circuits.

№ WARNING

To prevent damage or fire due to high temperature, ensure that the ventilation vents or heat dissipation systems are not obstructed or covered by other objects while the equipment is running.

General Requirements

- Ensure that the equipment is stored in a clean, dry, and well ventilated area with proper temperature and humidity and is protected from dust and condensation.
- Keep the installation and operating environments of the equipment within the allowed ranges. Otherwise, its performance and safety will be compromised.
- Do not install, use, or operate outdoor equipment and cables (including but not limited to moving equipment, operating equipment and cables, inserting connectors to or removing connectors from signal ports connected to outdoor facilities, working at heights, performing outdoor installation, and opening

doors) in harsh weather conditions such as lightning, rain, snow, and level 6 or stronger wind.

- Do not install the equipment in an environment with dust, smoke, volatile or corrosive gases, infrared and other radiations, organic solvents, or salty air.
- Do not install the equipment in an environment with conductive metal or magnetic dust.
- Do not install the equipment in an area conducive to the growth of microorganisms such as fungus or mildew.
- Do not install the equipment in an area with strong vibration, noise, or electromagnetic interference.
- Ensure that the site complies with local laws, regulations, and related standards.
- Ensure that the ground in the installation environment is solid, free from spongy or soft soil, and not prone to subsidence. The site must not be located in a low-lying land prone to water or snow accumulation, and the horizontal level of the site must be above the highest water level of that area in history.
- Do not install the equipment in a position that may be submerged in water.
- If the equipment is installed in a place with abundant vegetation, in addition to routine weeding, harden the ground underneath the equipment using cement or gravel (the area shall be greater than or equal to 3 m x 2.5 m).
- Do not install the equipment outdoors in salt-affected areas because it may be corroded. A salt-affected area refers to the region within 500 m of the coast or prone to sea breeze. Regions prone to sea breeze vary with weather conditions (such as typhoons and monsoons) or terrains (such as dams and hills).
- Before installation, operation, and maintenance, clean up any water, ice, snow, or other foreign objects on the top of the equipment.
- When installing the equipment, ensure that the installation surface is solid enough to bear the weight of the equipment.
- After installing the equipment, remove the packing materials such as cartons, foam, plastics, and cable ties from the equipment area.

1.4 Mechanical Safety

MARNING

Ensure that all necessary tools are ready and inspected by a professional organization. Do not use tools that have signs of scratches or fail to pass the inspection or whose inspection validity period has expired. Ensure that the tools are secure and not overloaded.

MARNING


Do not drill holes into the equipment. Doing so may affect the sealing performance and electromagnetic containment of the equipment and damage components or cables inside. Metal shavings from drilling may short-circuit boards inside the equipment.

General Requirements

- Repaint any paint scratches caused during equipment transportation or installation in a timely manner. Equipment with scratches must not be exposed for an extended period of time.
- Do not perform operations such as arc welding and cutting on the equipment without evaluation by the Company.
- Do not install other devices on the top of the equipment without evaluation by the Company.
- When performing operations over the top of the equipment, take measures to protect the equipment against damage.
- Use correct tools and operate them in the correct way.

Moving Heavy Objects

Be cautious to prevent injury when moving heavy objects.



- If multiple persons need to move a heavy object together, determine the manpower and work division with consideration of height and other conditions to ensure that the weight is equally distributed.
- If two persons or more move a heavy object together, ensure that the object is lifted and landed simultaneously and moved at a uniform pace under the supervision of one person.
- Wear personal protective gears such as protective gloves and shoes when manually moving the equipment.
- To move an object by hand, approach to the object, squat down, and then lift the object gently and stably by the force of the legs instead of your back. Do not lift it suddenly or turn your body around.
- Do not quickly lift a heavy object above your waist. Place the object on a workbench that is half-waist high or any other appropriate place, adjust the positions of your palms, and then lift it.
- Move a heavy object stably with balanced force at an even and low speed. Put
 down the object stably and slowly to prevent any collision or drop from
 scratching the surface of the equipment or damaging the components and
 cables.


- When moving a heavy object, be aware of the workbench, slope, staircase, and slippery places. When moving a heavy object through a door, ensure that the door is wide enough to move the object and avoid bumping or injury.
- When transferring a heavy object, move your feet instead of turning your waist around. When lifting and transferring a heavy object, ensure that your feet point to the target direction of movement.
- When transporting the equipment using a pallet truck or forklift, ensure that
 the tynes are properly positioned so that the equipment does not topple.
 Before moving the equipment, secure it to the pallet truck or forklift using
 ropes. When moving the equipment, assign dedicated personnel to take care
 of it.
- Choose sea, roads in good conditions, or airplanes for transportation. Do not transport the equipment by railway. Avoid tilt or jolt during transportation.

Using Ladders


- Use wooden or insulated ladders when you need to perform live-line working at heights.
- Platform ladders with protective rails are preferred. Single ladders are not recommended.
- Before using a ladder, check that it is intact and confirm its load bearing capacity. Do not overload it.
- Ensure that the ladder is securely positioned and held firm.



- When climbing up the ladder, keep your body stable and your center of gravity between the side rails, and do not overreach to the sides.
- When a step ladder is used, ensure that the pull ropes are secured.
- If a single ladder is used, the recommended angle for the ladder against the floor is 75 degrees, as shown in the following figure. A square can be used to measure the angle.




- If a single ladder is used, ensure that the wider end of the ladder is at the bottom, and take protective measures to prevent the ladder from sliding.
- If a single ladder is used, do not climb higher than the fourth rung of the ladder from the top.
- If you use a single ladder to climb up to a platform, ensure that the ladder is at least 1 m higher than the platform.



Hoisting

- Only trained and qualified personnel are allowed to perform hoisting operations.
- Install temporary warning signs or fences to isolate the hoisting area.
- Ensure that the foundation where hoisting is performed on meets the load-bearing requirements.
- Before hoisting objects, ensure that hoisting tools are firmly secured onto a fixed object or wall that meets the load-bearing requirements.
- During hoisting, do not stand or walk under the crane or the hoisted objects.
- Do not drag steel ropes and hoisting tools or bump the hoisted objects against hard objects during hoisting.
- Ensure that the angle between two hoisting ropes is no more than 90 degrees, as shown in the following figure.



Drilling Holes

- Obtain consent from the customer and contractor before drilling holes.
- Wear protective equipment such as safety goggles and protective gloves when drilling holes.
- To avoid short circuits or other risks, do not drill holes into buried pipes or cables.
- When drilling holes, protect the equipment from shavings. After drilling, clean up any shavings.

2 Overview

2.1 Product Introduction

Function

The SUN2000 inverter is a three-phase grid-tied PV string inverter that converts the DC power generated by PV strings into AC power and feeds the power into the power grid.

Model

This document covers the following SUN2000 models:

- SUN2000-20KTL-M3
- SUN2000-29.9KTL-M3
- SUN2000-30KTL-M3
- SUN2000-36KTL-M3
- SUN2000-40KTL-M3

■ NOTE

The SUN2000-20KTL-M3 supports 220 V (line voltage) power grids.

Figure 2-1 Model description (SUN2000-30KTL-M3 is used as an example)




Table 2-1 Model description

ID	Meaning	Value
1	Series name	SUN2000: grid-tied solar inverter


ID	Meaning	Value	
2	Power class	 20K: rated power of 20 kW 29.9K: rated power of 29.9 kW 30K: rated power of 30 kW 36K: rated power of 36 kW 40K: rated power of 40 kW 	
3	Topology	TL: transformerless	
4	Product code	M3: product series with an input voltage level of 1100 V DC ^a	

Note a: The maximum DC input voltage of SUN2000-20KTL-M3 is 800 V. For details, see **10 Technical Specifications**.

Networking Application

The SUN2000 applies to the grid-tied systems of industrial and commercial rooftops and small ground PV plants. Typically, a grid-tied system consists of PV strings, grid-tied inverters, AC switches, and power distribution units.

Figure 2-2 Networking application - single inverter scenario




- (1) PV string
- (2) SUN2000
- (3) AC power distribution unit

- (4) Isolation transformer
- (5) Power grid

Supported Power Grid Types

The SUN2000 supports TN-S, TN-C, TN-C-S, TT, and IT power grids.


Figure 2-3 Power grid types



IS01S10001

2.2 Appearance

Figure 2-4 Appearance



(1) LED indicator	(2) Front panel
(3) Heat sink	(4) Screw holes for fixing the awning
(5) Communications port (COM)	(6) Hole for the DC switch locking screw
(7) DC switch (DC SWITCH)	(8) Smart Dongle port (4G/WLAN-FE)
(9) Ventilation valve	(10) DC input terminals (PV1-PV8)
(11) AC output port	(12) Ground point

2.3 Label Description

Enclosure Labels

Symbol	Name	Description
Danger High Voltage! 高压危险! Start maintaining the INVERTER at least 5 minutes after the INVERTER disconnects from all external power supplies. 证变器与外部所有电源断开后,需要等待至少5分钟,才可以进行维护。	Delay discharge	Residual voltage exists after the SUN2000 is powered off. It takes 5 minutes for the SUN2000 to discharge to the safe voltage.
Warning: High Temperaturel高温危险 Never touch the enclosure of an operating INVERTER. 逆变器工作时严禁触摸外壳。	Burn warning	Do not touch a running SUN2000 because it generates high temperatures on the shell.
Danger. Electrical Hazardl 有电危险! Only certified professionals are allowed to install and operate the INVERTER. 仅有资质的专业人员才可进行 逆变器的安装和操作。 High touch current, earth connection essential before connecting supply. 大接触电流!接通电源前须先接地。	Electric shock warning	High voltage exists after the SUN2000 is powered on. Only qualified and trained electrical technicians are allowed to perform operations on the SUN2000.
		High touch current exists after the SUN2000 is powered on. Before powering on the SUN2000, ensure that the SUN2000 is properly grounded.

Symbol	Name	Description
Read instructions carefully before performing any operation on the INVERTER. 对逆变器进行任何操作前,请仔细阅读说明书!	Refer to documentation	Reminds operators to refer to the documents delivered with the SUN2000.
	Grounding label	Indicates the position for connecting the PE cable.
Do not disconnect under load! 禁止带负荷断开连接!	Operation warning	Do not remove the DC input connector or AC output connector with power on.
32-55 kg (70-121 lbs)	Weight label	The SUN2000 is heavy and needs to be carried by three persons.
Do not touch the handles within 10 minutes after the inverter is shut down! Não toque pelo menos 10 minutos após o inversor ser desligado! 关机10分钟后才能触碰!	Burn warning on inverter handles	Do not touch the handles within 10 minutes after the inverter is shut down.
Running indication LED 1	Indicator	Indicates the SUN2000 operating information.


Symbol	Name	Description
(1P)PNITEM:XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	SUN2000 serial number	Indicates the serial number.
WLAN SSID: SUN2000-XXXXXXXXXX Password:XXXXXXXX	SUN2000 Wi-Fi login QR code	Scan the QR code to connect to the Huawei SUN2000 Wi-Fi network.

2.4 Working Principles

2.4.1 Circuit Diagram

A SUN2000 can connect to a maximum of eight PV strings and has four MPPT circuits inside. Each MPPT circuit tracks the maximum power point of two PV strings. The SUN2000 converts DC power into single-phase AC power through an inverter circuit. Surge protection is supported on both the DC and AC sides.

Figure 2-5 Schematic diagram



2.4.2 Working Modes

The SUN2000 can work in Standby, Operating, or Shutdown mode.

Figure 2-6 Working modes




Table 2-2 Working mode description

Working Mode	Description
Standby	The SUN2000 enters Standby mode when the external environment does not meet the operating requirements. In Standby mode:
	The SUN2000 continuously performs status check and enters the Operating mode once the operating requirements are met.
	The SUN2000 enters Shutdown mode after detecting a shutdown command or a fault after startup.
Operating	In Operating mode:
	The SUN2000 converts DC power from PV strings into AC power and feeds the power to the power grid.
	The SUN2000 tracks the maximum power point to maximize the PV string output.
	If the SUN2000 detects a fault or a shutdown command, it enters the Shutdown mode.
	• The SUN2000 enters Standby mode after detecting that the PV string output power is not suitable for connecting to the power grid for generating power.
Shutdown	In Standby or Operating mode, the SUN2000 enters Shutdown mode after detecting a fault or shutdown command.
	In Shutdown mode, the SUN2000 enters Standby mode after detecting a startup command or that the fault is rectified.

User Manual 3 SUN2000 Storage

3 SUN2000 Storage

The following requirements should be met if the SUN2000 is not put into use directly:

- Do not unpack the SUN2000.
- Keep the storage temperature at -40°C to +70°C and the humidity at 5%-95% RH.
- Store inverters in a clean and dry place. Protect them from dust, rain, and water.
- Do not tilt the package or place it upside down.
- A maximum of six SUN2000s can be stacked. To avoid personal injury or device damage, stack SUN2000s with caution to prevent them from falling over.
- During the storage period, check the SUN2000 periodically (recommended: every three months). If any rodent bites are found on the packing materials, replace the packing materials immediately.
- If the SUN2000 has been stored for more than two years, it must be checked and tested by professionals before being put into use.



4.1 Checking Before Installation

Outer Packing Materials

Before unpacking the inverter, check the outer packing materials for damage, such as holes and cracks, and check the inverter model. If any damage is found or the inverter model is not what you requested, do not unpack the package and contact your supplier as soon as possible.

■ NOTE

You are advised to remove the packing materials within 24 hours before installing the inverter.

Package Contents

NOTICE

• After placing the equipment in the installation position, unpack it with care to prevent scratches. Keep the equipment stable during unpacking.

After unpacking the inverter, check that the contents are intact and complete. If any damage is found or any component is missing, contact your supplier.

■ NOTE

For details about the number of contents, see the *Packing List* in the packing case.

4.2 Tool Preparation

Туре	Tools and Instruments				
Install ation			(4)		
	Insulated torque socket wrench (including an extension bar)	Insulated torque socket wrench (including an extended socket)	Phillips insulated torque screwdriver		
	Hammer drill	Drill bit	Rubber mallet		
	Utility knife	Marker	Hydraulic pliers		
	Cable cutter	Wire stripper	Diagonal pliers		
	Crimping tool H4TC0003 (Amphenol)	Open-end wrench H4TW0001 (Amphenol)	Heat shrink tubing		

Туре	Tools and Instruments				
		₹ 0 ° . C			
	Crimping tool (model: PV-CZM-22100)	Open-end wrench (model: PV-MS-HZ or PV-MS open- end wrench)	Heat gun		
	Steel measuring tape	Level	Multimeter		
			-		
	Cable tie	Vacuum cleaner			
Person al protec tive equip ment (PPE)					
	Goggles	Work shoes	Dust mask		
	and the second s		-		
	Protective gloves	Insulated gloves			

4.3 Selecting an Installation Position

Basic Requirements

The SUN2000 is IP66-rated and can be installed indoors or outdoors.

- Do not install the SUN2000 in a place where a person can easily be exposed to its enclosure and heat sinks, because these parts are extremely hot during operation.
- Do not install the SUN2000 in areas with flammable or explosive materials.
- If the equipment is installed in a place with abundant vegetation, in addition to routine weeding, harden the ground underneath the equipment using cement or gravel (the area shall be greater than or equal to 3 m x 2.5 m).
- Do not install the SUN2000 in a place within children's reach.
- The SUN2000 will be corroded in salt areas, and the salt corrosion may cause fire. Do not install the SUN2000 outdoors in salt areas. A salt area refers to the region within 500 m from the coast or prone to sea breeze. The effect from sea breeze depends on weather conditions (such as typhoon and season wind) or terrains (such as dams and hills).

□ NOTE

The inverter shall be physically isolated from third-party wireless communications facilities and residential environments at a distance greater than 30 m.

Site Requirements

- The SUN2000 should be installed in a well-ventilated environment to ensure good heat dissipation.
- If the inverter is installed in an enclosed environment, a heat dissipation device or ventilation device shall be installed. The indoor ambient temperature must not be higher than the outdoor ambient temperature.
- If the SUN2000 is installed in a place exposed to direct sunlight, the power may decrease as the temperature rises.
- You are advised to install the SUN2000 in a sheltered place or install an awning over it.

Mounting Structure Requirements


- The mounting structure where the SUN2000 is installed must be fire resistant.
- Do not install the SUN2000 on flammable building materials.
- The SUN2000 is heavy. Ensure that the installation surface is solid enough to bear the weight load.
- In residential areas, do not install the SUN2000 on drywalls or walls made of similar materials which have a weak sound insulation performance because the noise generated by the SUN2000 is noticeable.

Installation Angle Requirements

The SUN2000 can be wall-mounted or support-mounted. Requirements for the installation angle:

- Install the SUN2000 vertically or at a maximum back tilt of 15 degrees to facilitate heat dissipation.
- Do not install the SUN2000 with a front tilt, excessive back tilt, side tilt, horizontally, or upside down.


Figure 4-1 Installation angle



Installation Space Requirements


 Reserve enough clearance around the SUN2000 to ensure sufficient space for installation and heat dissipation.

Figure 4-2 Installation space



• When installing multiple SUN2000s, install them in horizontal mode if ample space is available and install them in triangle mode if no ample space is available. Stacked installation is not recommended.

Figure 4-3 Horizontal installation (recommended)



Issue 17 (2024-02-02)

Figure 4-4 Two-layer triangle installation (recommended)





Figure 4-5 Three-layer triangle installation (not recommended)




M3

User Manual 4 Installation

≥ 300 mm ≥ 1000 mm IS13H00006

Figure 4-6 Stacked installation (not recommended)

Figure 4-7 Back-to-back installation (not recommended)



MOTE

The installation diagrams are for reference only and are irrelevant to the SUN2000 cascading scenario.

4.4 Moving the SUN2000


Procedure

Step 1 Lift the SUN2000 from the packing case and move it to the specified installation position.

CAUTION

- Move the SUN2000 with care to prevent device damage and personal injury.
- Do not use the wiring terminals and ports at the bottom to support any weight of the SUN2000.
- Place a foam pad or cardboard under the SUN2000 to protect the SUN2000 enclosure from damage.

Figure 4-8 Moving the SUN2000



----End

4.5 Installing the Mounting Bracket

Installation Precautions

Before installing the mounting bracket, remove the security Torx wrench and set it aside.

Figure 4-9 Position for binding the security Torx wrench



(1) Security Torx wrench

Figure 4-10 shows the dimensions of the mounting holes for the SUN2000.

640 mm

270 mm

226 mm

5 mm

152 mm

Figure 4-10 Mounting bracket dimensions

4.5.1 Support-mounted Installation

Procedure

Step 1 Secure the mounting bracket.

Φ14 mm

45 N·m

Figure 4-11 Securing the mounting bracket

□ NOTE

You are advised to apply anti-rust paint on the hole positions for protection.

4.5.2 Wall-mounted Installation

Prerequisites

To install the SUN2000, you need to prepare expansion bolts. M12x60 stainless steel expansion bolts are recommended.


Procedure

- **Step 1** Determine the positions for drilling holes and mark the positions using a marker.
- **Step 2** Secure the mounting bracket.

A DANGER

Avoid drilling holes in the water pipes and cables buried in the wall.

Figure 4-12 Expansion bolt composition



IS05W00018

(1) Bolt

(2) Nut

(3) Spring washer

- (4) Flat washer
- (5) Expansion sleeve

NOTICE

- To prevent dust inhalation or contact with eyes, wear safety goggles and an anti-dust mask when drilling holes.
- Clean up any dust in and around the holes using a vacuum cleaner and measure the distance between holes. If the holes are inaccurately positioned, drill holes again.
- Level the front of the expansion sleeve with the concrete wall after removing the bolt, spring washer, and flat washer. Otherwise, the mounting bracket will not be securely installed on the concrete wall.

Description of the control of the

Figure 4-13 Installing expansion bolts

----End


4.6 Installing a SUN2000

Step 1 (Optional) Install the locking screw for the DC switch.

Ⅲ NOTE


- The DC switch locking screw is used to lock the DC switch to prevent the switch from rotating.
- For models used in Australia, install the DC switch locking screw according to local standards. The DC switch locking screw is delivered with the SUN2000.

Figure 4-14 Installing the locking screw for the DC switch




Step 2 Install the SUN2000 onto the mounting bracket.

Figure 4-15 Installing a SUN2000



Step 3 Tighten the nuts on both sides of the SUN2000.

Figure 4-16 Tightening the nut



NOTICE

Secure the screws on the sides before connecting cables.

5 Electrical Connections

5.1 Precautions

DANGER

When exposed to sunlight, the PV arrays supply DC voltage to the inverter. Before connecting cables, ensure that all **DC SWITCH** on the inverter are OFF. Otherwise, the high voltage of the inverter may result in electric shocks.

DANGER

- The site must be equipped with qualified fire fighting facilities, such as fire sand and carbon dioxide fire extinguishers.
- Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

№ WARNING

- The equipment damage caused by incorrect cable connections is beyond the warranty scope.
- Only certified electrician can perform electrical terminations.
- Operation personnel must wear PPE when connecting cables.
- Before connecting cables to ports, leave enough slack to reduce the tension on the cables and prevent poor cable connections.

User Manual

♠ CAUTION

• Stay away from the equipment when preparing cables to prevent cable scraps from entering the equipment. Cable scraps may cause sparks and result in personal injury and equipment damage.

MOTE

The cable colors shown in the electrical connection diagrams provided in this section are for reference only. Select cables in accordance with local cable specifications (green-and-yellow cables are only used for protective earthing).

5.2 Preparing Cables

Figure 5-1 SUN2000 cable connections (dashed boxes indicate optional components)




Table 5-1 Components

No.	Component	Description	Source
A	PV string	 A PV string consists of PV modules connected in series. The SUN2000 supports the input from eight PV strings. 	Prepared by users

No.	Component	Description	Source
В	AC switch	To ensure that the inverter can be safely disconnected from the power grid when an exception occurs, connect an AC switch to the AC side of the inverter. Select an appropriate AC switch in accordance with local industry standards and regulations. Huawei recommends the following switch specifications:	Prepared by users
		Recommended: a three-phase AC circuit breaker with a rated voltage greater than or equal to 500 V AC and a rated current of:	
		• 63 A (SUN2000-29.9KTL/30KTL- M3)	
		• 80 A (SUN2000-20KTL-M3)	
		• 100 A (SUN2000-36KTL/40KTL- M3)	
С	Power meter ^[1]	The SUN2000 can connect to the DTSU666-H, DTSU666-HW, YDS60-80 and YDS60-C24 power meter. ^[2]	Purchased from Huawei
D	SUN2000	Select a proper model as required.	Purchased from Huawei
E	SmartLogger	SmartLogger3000	Purchased from Huawei
F	Smart Dongle	Select a proper model as required.	Purchased from Huawei
G	Smart PV optimizer ^[3]	MERC-1300W-P, MERC-1100W-P.	Purchased from Huawei

Note [1]: For details about meter operations, see *DTSU666-HW Smart Power Sensor Quick Guide*, *YDS60-80 Smart Power Sensor Quick Guide*, *YDS60-C24 Smart Power Sensor Quick Guide*, *DTSU666-H and DTSU666-H 250 A (50 mA) Smart Power Sensor Quick Guide* and *DTSU666-H 100 A and 250 A Smart Power Sensor User Manual*.

Note [2]: SUN2000MA V100R001C20SPC116 and later versions can connect to DTSU666-HW power meter.

Note [3]: For details about how to operate optimizers, see **MERC Smart PV Optimizer User Manual**.

NOTICE

The cable specifications must comply with local standards.

Table 5-2 Cable description

No.	Cable	Туре	Recommended Specifications	Source
1	DC input power cable	Common PV cable in the industry (Recommended model: PV1-F)	 Conductor cross-sectional area: 4-6 mm² Cable outer diameter: 5.5-9 mm 	Prepare d by users
2	AC output power cable	Outdoor copper-core/ aluminum-core cable	 Conductor cross-sectional area: 16-50 mm² outdoor coppercore cable or 35-50 mm² outdoor aluminum-core cable Cable outer diameter: 16-38 mm 	Prepare d by users
3	(Option al) Signal cable	Two-core outdoor shielded twisted pair (recommended model: DJYP2VP2-2x2x0.75)	 Conductor cross-sectional area: 0.2-1 mm² Cable outer diameter: 4-11 mm 	Prepare d by users
4	PE cable	Single-core outdoor copper-core cable	Conductor cross- sectional area ≥ 16 mm ²	Prepare d by users

Note a: Five-core cables with a cross-sectional area of 5 x 35 mm^2 or $5 \text{ x } 50 \text{ mm}^2$ are not supported.

NOTICE

If the SUN2000 is used with an optimizer, route the AC and DC power cables separate to avoid interference to the communication of the optimizer.

5.3 Connecting the PE Cable

A DANGER

- Ensure that the PE cable is securely connected. Otherwise, electric shocks may occur.
- Do not connect the neutral wire to the enclosure as a PE cable. Otherwise, electric shocks may occur.

Ⅲ NOTE

- The PE point at the AC output port is used only as a PE equipotential point, not a substitute for the PE point on the enclosure.
- It is recommended that silicone sealant or paint be applied around the ground terminal after the PE cable is connected.

Procedure

Step 1 Crimp OT terminals.

NOTICE

- Avoid scratching the core wire when stripping a cable.
- The cavity formed after the conductor crimp strip of the OT terminal is crimped must wrap the core wires completely. The core wires must contact the OT terminal closely.
- Wrap the wire crimping area with heat shrink tubing or PVC insulation tape. The heat shrink tubing is used as an example.
- When using a heat gun, protect devices from being scorched.




Figure 5-2 Crimping an OT terminal

- (1) Cable
- (2) Core


(3) Heat shrink tubing

- (4) OT terminal
- (5) Crimping tool
- (6) Heat gun

IS06Z00001

Step 2 Connect the PE cable.

Figure 5-3 Connecting the PE cable



(1) Reserved PE point

5.4 Connecting the AC Output Power Cable

Precautions

An AC switch must be installed on the AC side of the SUN2000 to ensure that the SUN2000 can be safely disconnected from the power grid.

№ WARNING

- Do not connect loads between the inverter and the AC switch that directly connects to the inverter. Otherwise, the switch may trip by mistake.
- If an AC switch is used with specifications beyond local standards, regulations, or Huawei's recommendations, the switch may fail to turn off in a timely manner in case of exceptions, causing serious faults.

CAUTION

Each inverter must be equipped with an AC output switch. Multiple inverters cannot connect to the same AC output switch.

NOTICE

- If the external AC switch can perform earth leakage protection, the rated leakage action current should be greater than or equal to 300 mA.
- If multiple SUN2000s connect to the general residual current device (RCD) through their respective external AC switches, the rated leakage action current of the general RCD should be greater than or equal to the number of SUN2000s multiplied by 300 mA.
- Use a socket wrench and extension rod to connect the AC power cable. The extension rod must be longer than 100 mm.
- Sufficient slack should be provided in the PE cable to ensure that the last cable bearing the force is the PE cable when the AC output power cable bears pulling force due to force majeure.
- Do not install third-party devices in the AC connection box.
- You need to prepare M8 OT terminals by yourself.
- If the AC MBUS is used, multi-core cables are recommended, supporting a maximum communication distance of 1000 m. To use other types of AC power cables, contact the Company's technical support.

Requirements for the OT or DT Terminal


- If a copper cable is used, use copper wiring terminals.
- If a copper-clad aluminum cable is used, use copper wiring terminals.

• If an aluminum alloy cable is used, use copper-aluminum transition wiring terminals, or aluminum wiring terminals along with copper-aluminum transition spacers.

NOTICE

- Do not connect aluminum wiring terminals to the AC terminal block. Otherwise the electrochemical corrosion will occur and affect the reliability of cable connections.
- Comply with the IEC61238-1 requirements when using copper-aluminum transition wiring terminals, or aluminum wiring terminals along with copper-aluminum transition spacers.
- If copper-aluminum transition spacers are used, pay attention to the front and rear sides. Ensure that the aluminum sides of spacers are in contact with aluminum wiring terminals, and copper sides of spacers are in contact with the AC terminal block.


Figure 5-4 Requirements for the OT/DT terminal



Procedure

Step 1 Remove the AC terminal box and install partition boards.

Figure 5-5 Removing the AC terminal box




Step 2 Connect the AC output power cable.

□ NOTE

- To avoid damaging the rubber liner, do not route a cable with a crimped OT terminal directly through it.
- Sufficient slack should be provided in the PE cable to ensure that the last cable bearing
 the force is the PE cable when the AC output power cable bears pulling force due to
 force majeure. It is recommended that the length of the PE cable to be stripped be 15
 mm longer than the length of other cables.
- The cable colors in figures are for reference only. Select appropriate cables according to the local standards.


Figure 5-6 Stripping the AC power cable (using a five-core cable as an example)



S13120002

Figure 5-7 Five-core cable (L1, L2, L3, N, and PE)

Figure 5-8 Four-core cable (L1, L2, L3, and PE)



User Manual

8 N·m

Figure 5-9 Four-core cable (L1, L2, L3, and N)

IS13I20005

Figure 5-10 Three-core cable (L1, L2, and L3)





Figure 5-11 Wiring requirements



----End

5.5 Installing the DC Input Power Cable

5.5.1 Cable Connection Description

Precautions

A DANGER

- Before connecting the DC input power cables, ensure that the DC voltage is within the safe range (lower than 60 V DC) and that the DC switch on the inverter is OFF. Failing to do so may result in electric shocks.
- When the inverter is running, it is not allowed to work on the DC input power cables, such as connecting or disconnecting a PV string or a PV module in a PV string. Failing to do so may cause electric shocks.
- If no PV string connects to a DC input terminal of the inverter, do not remove the watertight cap from the DC input terminals. Otherwise, the IP rating of the inverter will be affected.

№ WARNING

Ensure that the following conditions are met. Otherwise, the SUN2000 may be damaged, or even a fire could happen.

- PV modules connected in series in each PV string are of the same specifications.
- The DC input voltage of the SUN2000-29.9KTL/30KTL/36KTL/40KTL-M3 shall not exceed 1100 V DC under any circumstance.
- The DC input voltage of the SUN2000-20KTL-M3 shall not exceed 800 V DC under any circumstance.
- The polarities of electric connections are correct on the DC input side. The positive and negative terminals of a PV string connect to corresponding positive and negative DC input terminals of the SUN2000.
- If polarity of the DC input power cable is reversed and the DC switch is ON, do
 not turn off the DC switch immediately or remove positive and negative
 connectors. Wait until the solar irradiance declines at night and the PV string
 current reduces to below 0.5 A, and then turn off the DC switch and remove
 the positive and negative connectors. Correct the PV string polarity before
 reconnecting the PV string to the SUN2000.


↑ WARNING

During the installation of PV strings and the SUN2000, the positive or negative terminals of PV strings may be short-circuited to ground if the power cables are not properly installed or routed. In this case, an AC or DC short circuit may occur and damage the SUN2000. The resulting device damage is not covered under any warranty.

NOTICE

- The SUN2000 does not support power supplies other than PV strings. Since the output of the PV string connected to the SUN2000 cannot be grounded, ensure that the PV module output is well insulated to ground.
- The voltage difference between MPPTs shall be less than 85 V to achieve optimal power generation of the system.

Figure 5-12 DC input terminals



When the DC input is not fully configured, the DC input terminals must meet the following requirements:

- 1. Distribute the DC input power cables evenly over four MPPT circuits, and connect them preferentially through MPPT1 and MPPT4.
- 2. Maximize the number of connected MPPT circuits.

Number of PV Strings	Terminal Selection	Number of PV Strings	Terminal Selection
1	PV1	2	PV1 and PV7
3	PV1, PV3 and PV7	4	PV1, PV3, PV5 and PV7
5	PV1, PV2, PV3, PV5 and PV7	6	PV1, PV2, PV3, PV5, PV7 and PV8
7	PV1, PV2, PV3, PV4, PV5, PV7 and PV8	8	PV1, PV2, PV3, PV4, PV5, PV6, PV7 and PV8

5.5.2 Connecting Cables to Amphenol Helios H4 Connectors



Use the positive and negative Amphenol Helios H4 metal terminals and DC connectors supplied with the solar inverter. Using incompatible positive and negative metal terminals and DC connectors may result in serious consequences. The caused device damage is not covered under any warranty.

NOTICE


- You are advised to use the H4TC0003 (Amphenol) crimping tool and do not use it with the positioning block. Otherwise, the metal terminals may be damaged.
- The H4TW0001 (Amphenol) open-end wrench is recommended.
- Cables with high rigidity, such as armored cables, are not recommended as DC input power cables, because poor contact may be caused by the bending of the cables.
- Before assembling DC connectors, label the cable polarities correctly to ensure correct cable connections.
- After the positive and negative connectors snap into place, pull the DC input cables back to ensure that they are connected securely.
- If the SUN2000 is used with an optimizer, the number of optimizers for a single PV string cannot exceed 25.
- If the PV string is configured with an optimizer, check the cable polarity by referring to the smart PV optimizer quick guide.

5 Electrical Connections

Procedure

Step 1 Connect the DC power cable.

Figure 5-13 Connecting the DC power cable



----End

NOTICE

During DC input power cabling, leave at least 50 mm of slack. The axial tension on PV connectors must not exceed 80 N. Radial stress or torque must not be generated on PV connectors.

5.5.3 Connecting Cables to Staubli MC4 Connectors



Use the positive and negative Staubli MC4 metal terminals and DC connectors supplied with the SUN2000. Using incompatible positive and negative metal terminals and DC connectors may result in serious consequences. The caused device damage is not covered under warranty.

NOTICE

- You are advised to use the PV-CZM-22100 (Staubli) crimping tool and do not use it with the positioning block. Otherwise, the metal terminals may be damaged.
- The PV-MS (Staubli) or PV-MS-HZ (Staubli) open-end wrench is recommended.
- Cables with high rigidity, such as armored cables, are not recommended as DC input power cables, because poor contact may be caused by the bending of the cables.
- Before assembling DC connectors, label the cable polarities correctly to ensure correct cable connections.
- After the positive and negative connectors snap into place, pull the DC input cables back to ensure that they are connected securely.
- If the SUN2000 is used with an optimizer, the number of optimizers for a single PV string cannot exceed 25.
- If the PV string is configured with an optimizer, check the cable polarity by referring to the smart PV optimizer quick quide.

Procedure

User Manual

Step 1 Connect the DC power cable.

Positive metal Positive connector Use the wrench BIC (81) contact shown in the figure to 8-10 mm tighten the locking nut. When the wrench 12 T slips during the **□** PV-CZM-22100 Negative tightening, the 8-10 mm Ensure that the cable Click connector locking nut has been Negative metal cannot be pulled out tightened. after being crimped. contact Ensure that the cables PV+ are correctly connected. PV-MS-HZ Open-end wrench Click

Figure 5-14 Connecting the DC power cable

----End

NOTICE

During DC input power cabling, leave at least 50 mm of slack. The axial tension on PV connectors must not exceed 80 N. Radial stress or torque must not be generated on PV connectors.

IS13I30001

5.6 (Optional) Installing the Smart Dongle

Procedure


The Smart Dongle is not provided in standard configuration.


4G Smart Dongle


NOTICE

- If your Smart Dongle is not equipped with a SIM card, prepare a standard SIM card by yourself (size: 25 mm x 15 mm) with the capacity greater than or equal to 64 KB.
- When installing the SIM card, determine its installation direction based on the silk screen and arrow on the card slot.
- Press the SIM card in place to lock it, indicating that the SIM card is correctly installed.
- When removing the SIM card, push it inward to eject it.
- When reinstalling the enclosure of the Smart Dongle, ensure that the snapfits click into place.

Figure 5-15 Installing the 4G Smart Dongle (SDongleA-03)









IS10H00016

User Manual




Figure 5-16 Installing the 4G Smart Dongle (SDongleB-06)


WLAN-FE Smart Dongle (WLAN communication)

Figure 5-17 Installing the WLAN-FE Smart Dongle (WLAN communication)



WLAN-FE Smart Dongle (FE communication)

Figure 5-18 Installing the WLAN-FE Smart Dongle (FE communication)



User Manual

NOTICE

Install the network cable before installing the Smart Dongle on the inverter.

◯ NOTE

 For details about how to use the WLAN-FE Smart Dongle SDongleA-05, see SDongleA-05 Smart Dongle Quick Guide (WLAN-FE). You can scan the QR code below to obtain the document.



• For details about how to use the 4G Smart Dongle SDongleA-03, see **SDongleA-03 Quick Guide (4G)**. You can scan the QR code below to obtain the document.



For details about how to use the 4G Smart Dongle SDongleB-06, see SDongleB-06
 Smart Dongle Quick Guide (4G). You can scan the QR code below to obtain the document



The quick guide is delivered with the Smart Dongle.


5.7 Connecting the Signal Cable

COM Port Pin Definitions

NOTICE

When laying out a signal cable, separate it from power cables to avoid strong signal interference.





Pin	Definitio n	Function	Description	Pin	Definitio n	Function	Description
1	485A1_1	RS485 differential signal +	Used to cascade inverters or	2	485A1_2	RS485 differential signal +	Used to cascade inverters or connect to the SmartLogger.
3	485B1_1	RS485 differential signal –	connect to the SmartLogger.	4	485B1_2	RS485 differential signal –	
5	PE	Ground point on the shield layer	-	6	PE	Ground point on the shield layer	-
7	485A2	RS485 differential signal +	Connects to the RS485 signal port for	8	DIN1	Dry contact for power grid	-
9	485B2	RS485 differential signal –	controlling the power meter at the grid-tied point.	10	DIN2	scheduling	
11	-	-	-	12	DIN3		
13	GND	GND	-	14	DIN4		


Pin	Definitio n	Function	Description	Pin	Definitio n	Function	Description
15	DIN5	Rapid shutdown/NS protection	Used to connect to the rapid shutdown DI signal port or serve as a port for the signal cable of the NS protection.	16	GND		

Scenarios Where No Signal Cable Is Connected

NOTICE

If no signal cable is required for the SUN2000, use waterproof plugs to block the wiring holes on the signal cable connector and connect the signal cable connector to the communications port on the SUN2000 to improve the waterproof performance of the SUN2000.

Figure 5-20 Securing the signal cable connector



5 Electrical Connections


5.7.1 Communication Modes

RS485 Communication

User Manual

Smart Dongle networking

Figure 5-21 Smart Dongle networking




◯ NOTE

If a SUN2000 is networked using a Smart Dongle, it cannot be connected to the SmartLogger.

SmartLogger networking

Figure 5-22 SmartLogger networking



Ⅲ NOTE

- If a SUN2000 is networked using the SmartLogger, it cannot be connected to a Smart Dongle.
- It is recommended that the number of SUN2000s connected to each RS485 route be less than 30.

MBUS Communication

The MBUS is a communication mode in which communication signals are loaded to power cables through the communications board for transmission.

□ NOTE

User Manual

- See the device nameplate to check whether the MBUS is supported.
- Inverters manufactured after July 20, 2022 do not support the AC MBUS.
- The built-in MBUS module in the SUN2000 does not need to be connected with cables.
- In utility-scale scenarios, an isolation transformer must be connected between inverters and loads.
- Commercial and industrial scenarios are supported only in China.

Figure 5-23 MBUS communication (utility-scale scenarios)





Figure 5-24 MBUS communication (commercial and industrial scenarios in China)




User Manual 5 Electrical Connections

5.7.2 (Optional) Connecting the RS485 Communications Cable to the SUN2000

Procedure


Step 1 Connect the signal cable to the signal cable connector.

Figure 5-25 Connecting the cable



Step 2 Connect the signal cable connector to the COM port.

Figure 5-26 Securing the signal cable connector



IS13I40001


User Manual 5 Electrical Connections

5.7.3 (Optional) Connecting the RS485 Communications Cable to the Power Meter

Procedure

Step 1 Connect the signal cable to the signal cable connector.


Figure 5-27 Connecting the cable



IS10I20008

Step 2 Connect the signal cable connector to the COM port.

Figure 5-28 Securing the signal cable connector



IS13I40001


User Manual 5 Electrical Connections

5.7.4 (Optional) Connecting the Power Grid Scheduling Signal Cable

Procedure

Step 1 Connect the signal cable to the signal cable connector.


Figure 5-29 Connecting the cable



IS10I20010

Step 2 Connect the signal cable connector to the COM port.

Figure 5-30 Securing the signal cable connector



IS13I40001


5 Electrical Connections

5.7.5 (Optional) Connecting the Rapid Shutdown Signal Cable

Procedure

Step 1 Connect the signal cable to the signal cable connector.


Figure 5-31 Connecting the cable



IS13I40004

Step 2 Connect the signal cable connector to the COM port.

Figure 5-32 Securing the signal cable connector



IS13I40001

User Manual 6 Commissioning

6 Commissioning

⚠ DANGER

• Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

6.1 Checking Before Power-On

Table 6-1 Checklist

No.	Check Item	Acceptance Criteria
1	SUN2000 installation	The SUN2000 is installed correctly and securely.
2	Smart Dongle	The Smart Dongle is installed correctly and securely.
3	Cable routing	The cables are routed properly as required by the customer.
4	Cable ties	Cable ties are evenly distributed and no burr exists.
5	Reliable grounding	The PE cable is connected correctly and securely.
6	Switch	DC switches and all the switches connecting to the SUN2000 are OFF.
7	Cable connection	The AC output power cable, and DC input power cables are connected correctly and securely.
8	Unused terminals and ports	Unused terminals and ports are locked by watertight caps.

User Manual 6 Commissioning

No.	Check Item	Acceptance Criteria
9	Installation environment	The installation space is proper, and the installation environment is clean and tidy.

6.2 System Power-On

Prerequisites

DANGER

 Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.


NOTICE

- Before turning on the AC switch between the SUN2000 and the power grid, check that the AC voltage is within the specified range using a multimeter.
- If the DC power supply is connected but the AC power supply is disconnected, the SUN2000 will report a **Grid Loss** alarm. The SUN2000 can start properly only after the power grid recovers.

Procedure

- **Step 1** Turn on the AC switch between the SUN2000 and the power grid.
- **Step 2** (Optional) Remove the locking screw beside the DC switch.

Figure 6-1 Removing the locking screw beside the DC switch



- Step 3 Turn on the DC switch at the bottom of the SUN2000.
- **Step 4** Observe the LED indicators to check the operating status of the SUN2000.

User Manual 6 Commissioning

Table 6-2 Indicator description

Category	Status	Description	
Running	LED1	LED2	-
indicator	Steady green	Steady green	The SUN2000 is operating in gridtied mode.
LED1 LED2	Blinking green slowly (on for 1s and off for 1s)	Off	The DC is on and the AC is off.
	Blinking green slowly (on for 1s and off for 1s)	Blinking green slowly (on for 1s and off for 1s)	Both the DC and AC are on, and the SUN2000 is not supplying power to the power grid.
	Off	Blinking green slowly	The DC is off and the AC is on.
	Off	Off	Both the DC and AC are off.
	Blinking red fast (on for 0.2s and off for 0.2s)	_	DC environment alarm
	_	Blinking red fast (on for 0.2s and off for 0.2s)	AC environment alarm
	Steady red	Steady red	Faulty
Communications	LED3		-
indicator □□ □ (φ) □□ □ □	Blinking green fast (on for 0.2s and then off for 0.2s)		Communication is in progress.
LED3	Blinking green slowly (on for 1s and off for 1s)		A mobile phone is connected.
	Off		No communication

Note: If LED1, LED2, and LED3 are steady red, the SUN2000 is faulty and needs to be replaced.

Man-Machine Interaction

□ NOTE

- If the SUN2000 is connected to the FusionSolar Smart PV Management System, the FusionSolar app is recommended. In areas where the FusionSolar app is not available, or when a third-party management system is used, only the SUN2000 app can be used for commissioning.
- Access the Huawei app store, search for FusionSolar or SUN2000, and download the app installation package. You can also scan the QR codes below to download the apps.







FusionSolar

SUN2000 (Android)

SUN2000 (iOS)

NOTICE

- The screenshots are for reference only. The actual screens may vary.
- Obtain the initial password for connecting to the solar inverter WLAN from the label on the side of the solar inverter.
- Set the password at the first login. To ensure account security, change the
 password periodically and keep the new password in mind. Not changing the
 password may cause password disclosure. A password left unchanged for a long
 period of time may be stolen or cracked. If a password is lost, devices cannot
 be accessed. In these cases, the user is liable for any loss caused to the PV
 plant
- Set the correct grid code based on the application area and scenario of the SUN2000.

7.1 Scenario in Which SUN2000s Are Connected to the FusionSolar Smart PV Management System


7.1.1 (Optional) Registering an Installer Account

□ NOTE

- If you have an installer account, skip this step.
- You can register an account only using a mobile phone only in China.
- The mobile number or email address used for registration is the user name for logging in to the FusionSolar app.

Create the first installer account and create a domain named after the company name.

Figure 7-1 Creating the first installer account



NOTICE

To create multiple installer accounts for a company, log in to the FusionSolar app and tap **Add User** to create an installer account.




Figure 7-2 Creating multiple installer accounts for the same company

7.1.2 Creating a PV Plant and a User

Plants Statistics Add user **FusionSolar** 0 0 0 Normal Offline Faulty Q Enter a plant name. 磊 了 Username or email Ø Password No account? Forgot password? Demo site No data available. ٧S ر©ا https://antohill.fusionsolar.huawei.com

Figure 7-3 Creating a PV plant and a user

□ NOTE

- In the quick settings for SUN2000-(29.9KTL/36KTL/40KTL)-M3, the grid code is N/A by default (automatic startup is not supported). Set the grid code based on the area where the PV plant is located.
- Before the equipment is put into operation for the first time, ensure that the parameters
 are set correctly by professional personnel. Incorrect parameter settings may result in
 noncompliance with local grid connection requirements and affect the normal
 operations of the equipment.
- For details about how to use the site deployment wizard, see FusionSolar App Quick Guide.



7.1.3 SmartLogger Networking Scenario

For details, see *PV Plants Connecting to Huawei Hosting Cloud Quick Guide* (Inverters + SmartLogger3000), *PV Plants Connecting to SmartPVMS Quick Guide* (Inverters + SmartLogger3000 + RS485 Networking) and *PV Plants Connecting to SmartPVMS Quick Guide* (Inverters + SmartLogger3000 + MBUS Networking).

□ NOTE

Inverters manufactured after July 20, 2022 do not support the AC MBUS.

7.2 Scenario in Which SUN2000s Are Connected to Other Management Systems

- **Step 1** Open the SUN2000 app, scan the QR code of the SUN2000 or manually connect to the WLAN hotspot to access the device commissioning screen.
- **Step 2** Select **installer** and enter the login password.
- **Step 3** Tap **Log in** to access the quick settings screen or SUN2000 home screen.

Figure 7-4 Logging In to the app



----End

7.3 Energy Control

7.3.1 Grid-tied Point Control

Function

Limits or reduces the output power of the PV power system to ensure that the output power is within the specified range.

Procedure

Step 1 On the home screen, choose Power adjustment > Grid-tied point control.






Table 7-1 Grid-tied point control

Paramet	ter		Description
Active power	Unlimite d	-	If this parameter is set to Unlimited , the output power of the SUN2000 is not limited and the SUN2000 can connect to the power grid at the rated power.
	Grid connecti on with zero power	Closed-loop controller	 If multiple SUN2000s are cascaded, set this parameter to SDongle/SmartLogger. If there is only one SUN2000, set this parameter to Inverter.
	power	Limitation mode	Total power indicates export limitation of the total power at the grid-tied point. (When a single-phase meter is connected, only Total power can be selected. If a three-phase meter is connected in three-phase three-wire mode, only Total power can be selected.)
			Single-phase power indicates export limitation of the power in each phase at the grid-tied point. If a three-phase meter is connected, Single-phase power can be selected only when the meter is connected in three-phase four-wire mode.
			Power adjustment period
		Maximum protection time	Specifies the time for detecting power meter data. If the Dongle does not detect any power meter data within the preset time, the Dongle delivers the preset value of Active power output limit for fail-safe for protection.
		Power raising threshold	Specifies the step for grid-tied power adjustment.

Paramet	er		Description
		Active power output limit for fail-safe	Specifies the derating value of the SUN2000 active power by percentage. If the Smart Dongle does not detect any meter data or the communication between the Smart Dongle and the SUN2000 is disconnected, the Smart Dongle delivers the derating value of the SUN2000 active power by percentage.
		Communicatio n disconnection fail-safe	In the inverter export limitation scenario, if this parameter is set to Enable , the inverter will derate according to the active power derating percentage when the communication between the inverter and the Smart Dongle is disconnected for a period longer than Communication disconnection detection time .
		Communicatio n disconnection detection time	Specifies the fail-safe detection time for the disconnection between the SUN2000 and the Smart Dongle. This parameter is displayed when Communication disconnection fail-safe is enabled.
	Grid connecti on with limited power (kW)	Closed-loop controller	 If multiple SUN2000s are cascaded, set this parameter to SDongle/SmartLogger. If there is only one SUN2000, set this parameter to Inverter.
		Limitation mode	Total power indicates export limitation of the total power at the grid-tied point. (When a single-phase meter is connected, only Total power can be selected. If a three-phase meter is connected in three-phase three-wire mode, only Total power can be selected.)
			Single-phase power indicates export limitation of the power in each phase at the grid-tied point. If a three-phase meter is connected, Single-phase power can be selected only when the meter is connected in three-phase four-wire mode.
		Maximum grid feed-in power	Specifies the maximum active power transmitted from the grid-tied point to the power grid.
		Power adjustment period	Specifies the shortest interval for a single export limitation adjustment.
		Maximum protection time	Specifies the time for detecting power meter data. If the Dongle does not detect any power meter data within the preset time, the Dongle delivers the preset value of Active power output limit for fail-safe for protection.
		Power raising threshold	Specifies the step for grid-tied power adjustment.

Paramet	er		Description
		Power adjustment period	Specifies the shortest interval for a single export limitation adjustment.
		Active power output limit for fail-safe	Specifies the derating value of the inverter active power by percentage. If the Smart Dongle does not detect any power meter data or the communication between the Smart Dongle and the inverter is disconnected, the Smart Dongle delivers the derating value of the inverter active power by percentage.
		Communicatio n disconnection fail-safe	In the inverter export limitation scenario, if this parameter is set to Enable , the inverter will derate according to the active power derating percentage when the communication between the inverter and the Smart Dongle is disconnected for a period longer than Communication disconnection detection time .
		Communicatio n disconnection detection time	Specifies the time for determining the communication disconnection between the inverter and the Smart Dongle. This parameter is displayed when Communication disconnection fail-safe is set to Enable .
	Grid connecti on with limited power (%)	Closed-loop controller	 For a single inverter, set Closed-loop controller to Inverter. For multiple inverters, Closed-loop controller can only be set to SDongle/SmartLogger.
		Limitation mode	Total power indicates export limitation of the total power at the grid-tied point. (When a single-phase meter is connected, only Total power can be selected. If a three-phase meter is connected in three-phase three-wire mode, only Total power can be selected.)
			Single-phase power indicates export limitation of the power in each phase at the grid-tied point. If a three-phase meter is connected, Single-phase power can be selected only when the meter is connected in three-phase four-wire mode.
		PV plant capacity	Specifies the total maximum active power in the inverter cascading scenario.
		Maximum grid feed-in power	Specifies the percentage of the maximum active power of the grid-tied point to the PV plant capacity.
		Maximum protection time	Specifies the time for detecting power meter data. If the Dongle does not detect any power meter data within the preset time, the Dongle delivers the preset value of Active power output limit for fail-safe for protection.
		Power raising threshold	Specifies the step for grid-tied power adjustment.

Paramete	er		Description
		Power adjustment period	Specifies the shortest interval for a single export limitation adjustment.
		Active power output limit for fail-safe	Specifies the derating value of the inverter active power by percentage. If the Smart Dongle does not detect any power meter data or the communication between the Smart Dongle and the inverter is disconnected, the Smart Dongle delivers the derating value of the inverter active power by percentage.
		Communicatio n disconnection fail-safe	In the inverter export limitation scenario, if this parameter is set to Enable , the inverter will derate according to the active power derating percentage when the communication between the inverter and the Smart Dongle is disconnected for a period longer than Communication disconnection detection time .
		Communicatio n disconnection detection time	Specifies the time for determining the communication disconnection between the inverter and the Smart Dongle. This parameter is displayed when Communication disconnection fail-safe is set to Enable .
Shutdo		at high feed-in	The default value is Disable .
wn at high feed-in power ¹	power		If this parameter is set to Enable , the inverter shuts down for protection when the grid-connection point power exceeds the threshold and remains in this condition for the specified time threshold.
		d-in power for inverter (kW)	The default value is 0 . This parameter specifies the power threshold of the grid-connection point for triggering inverter shutdown.
	triggering	hreshold for inverter	The default value is 20 . This parameter specifies the duration threshold of high feed-in power for triggering inverter shutdown.
	shutdown (s)		 When High feed-in power duration threshold for triggering inverter shutdown is set to 5. Shutdown at high feed-in power takes precedence.
			When High feed-in power duration threshold for triggering inverter shutdown is set to 20, Grid connection with limited power takes precedence (when Active power control is set to Grid connection with limited power).
Note 1: T	his parame	eter is supported c	only for the AS4777 grid code.

----End

7.3.2 Apparent Power Control on the Inverter Output Side

On the home screen, tap **Settings > Power adjustment** to set inverter parameters.

Figure 7-6 Apparent power control




Table 7-2 Apparent power

Parameter	Description	Value Range	
Maximum apparent power (kVA)	Specifies the output upper threshold for the maximum apparent power to adapt to the capacity requirements of standard and customized inverters.	[Maximum active power, S _{max}]	
Maximum active power (kW)	Specifies the output upper threshold for the maximum active power to adapt to different market requirements.	[0.1, P _{max}]	

□ NOTE

The lower threshold for the maximum apparent power is the maximum active power. To lower the maximum apparent power, lower the maximum active power first.

User Manual 8 Maintenance

8 Maintenance

DANGER

 Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

MARNING

• Before performing maintenance, power off the equipment, follow the instructions on the delayed discharge label, and wait for a period of time as specified to ensure that the equipment is not energized.

8.1 System Power-Off

Precautions

№ WARNING


After the SUN2000 powers off, the remaining electricity and heat may still cause electric shocks and body burns. Therefore, put on protective gloves and begin operating the SUN2000 five minutes after the power-off.

Procedure

- **Step 1** Send a shutdown command on the app.
- **Step 2** Turn off the AC switch between the SUN2000 and the power grid.
- **Step 3** Turn off the DC switch at the bottom of the SUN2000.
- **Step 4** (Optional) Install the locking screw for the DC switch.

User Manual 8 Maintenance

Figure 8-1 Installing the locking screw for the DC switch



Step 5 Turn on the DC switch between the PV string and the SUN2000 if there is any. ----End

8.2 Routine Maintenance

To ensure that the SUN2000 can operate properly for a long term, you are advised to perform routine maintenance on it as described in this chapter.



Before cleaning the system, connecting cables, and ensuring the grounding reliability, power off the system.

Table 8-1 Maintenance checklist

Check Item	Check Method	Maintenance Interval
System cleanliness	Check periodically that the heat sinks are free from obstacles and dust.	Once every 6 to 12 months
System operating status	 Check that the SUN2000 is not damaged or deformed. Check that the SUN2000 operates with no abnormal sound. Check that all SUN2000 parameters are correctly set during operation. 	Once every 6 months
Electrical connection	 Check that cables are secured. Check that cables are intact, and that in particular, the parts touching the metallic surface are not scratched. 	The first inspection is 6 months after the initial commissioning. From then on, the interval can be 6 to 12 months.

User Manual 8 Maintenance

Check Item	Check Method	Maintenance Interval
Grounding reliability	Check that ground cables are securely connected.	The first inspection is 6 months after the initial commissioning. From then on, the interval can be 6 to 12 months.
Air tightness	Check that all terminals and ports are properly sealed.	Once a year
Clear vegetation around the inverters	 Perform inspection and weeding as required. Clean the site promptly after weeding. 	Based on the local wilting season

8.3 Alarm Reference

For details about alarms, see the **Inverter Alarm Reference**.

9 Handling the Inverter

9.1 Removing the SUN2000

NOTICE

Before removing the SUN2000, disconnect both AC and DC connections.

Perform the following operations to remove the SUN2000:

- 1. Disconnect all cables from the SUN2000, including RS485 communications cables, DC input power cables, AC output power cables, and PGND cables.
- 2. Remove the SUN2000 from the mounting bracket.
- 3. Remove the mounting bracket.

9.2 Packing the SUN2000

- If the original packing materials are available, put the SUN2000 inside them and then seal them by using adhesive tape.
- If the original packing materials are not available, put the SUN2000 inside a suitable cardboard box and seal it properly.

9.3 Disposing of the SUN2000

If the SUN2000 service life expires, dispose of it according to the local disposal rules for electrical equipment waste.

10 Technical Specifications

Efficiency

Technical	SUN2000-20K	SUN2000-29.	SUN2000-30K	SUN2000-36K	SUN2000-40K
Specifications	TL-M3	9KTL-M3	TL-M3	TL-M3	TL-M3
Peak	97.1%	98.65%/400 V	98.65%/400 V	98.65%/400 V	98.65%/400 V
efficiency		98.75%/480 V	98.75%/480 V	98.75%/480 V	98.75%/480 V
European	96.7%	98.4%/400 V	98.4%/400 V	98.4%/400 V	98.4%/400 V
efficiency		98.45%/480 V	98.45%/480 V	98.5%/480 V	98.5%/480 V

Input

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3
Recommende d maximum DC input power	30,000 W	44,850 W	45,000 W	54,000 W	60,000 W
Maximum input voltage ^a	800 V	1100 V			
Maximum input current (per MPPT)	27 A				
Maximum short-circuit current (per MPPT)	40 A				
Minimum startup voltage	200 V				

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3
Operating voltage range ^b	200-750 V	200-1000 V			
Full power MPPT voltage range ^c	300-550 V	500-800 V/400 V AC 625-850 V/480 V AC	500-800 V/ (380 V AC, 400 V AC) 625-850 V/440 V AC 625-850 V/480 V AC	520-800 V/ (380 V AC, 400 V AC) 625-850 V/440 V AC 625-850 V/480 V AC	540-800 V/ (380 V AC, 400 V AC) 625-850 V/440 V AC 625-850 V/480 V AC
Rated input voltage	350 V	600 V (400 V AC) 720 V (480 V AC)	600 V (380 V AC, 400 V AC) 650 V (440 V AC) 720 V (480 V AC)	600 V (380 V AC, 400 V AC) 650 V (440 V AC) 720 V (480 V AC)	600 V (380 V AC, 400 V AC) 650 V (440 V AC) 720 V (480 V AC)
Maximum number of inputs	8				
Number of MPPTs	4				

Note a: The maximum input voltage is the maximum DC input voltage that the SUN2000 can withstand. If the input voltage exceeds this value, the SUN2000 may be damaged.

Note b: If the input voltage is beyond the operating voltage range, the solar inverter cannot work properly.

Note c: PV strings connecting to the same MPPT must contain the same quantity and model of PV modules. It is recommended that the PV string voltage be higher than the lower threshold of the full-load MPPT voltage.

Output

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3
Rated output power	20,000 W	29,900 W	30,000 W	36,000 W	40,000 W
Maximum apparent power	22,000 VA	29,900 VA	33,000 VA ^a	40,000 VA	44,000 VA

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3
Maximum active power (cosφ = 1)	22,000 W	29,900 W	33,000 W ^a	40,000 W	44,000 W
Rated output voltage ^b	127 V AC (220 V AC), 230 V AC (400 V AC), 3 W + (N) ^c + PE	230 V AC (400 V AC), 277 V AC (480 V AC), 3 W + (N) ^c + PE	220 V AC (380 V AC), 230 V AC (400 V AC), 254 V AC (440 V AC), 277 V AC (480 V AC), 3 W + (N) ^c + PE	220 V AC (380 V AC), 230 V AC (400 V AC), 254 V AC (440 V AC), 277 V AC (480 V AC), 3 W + (N) ^c + PE	220 V AC (380 V AC), 230 V AC (400 V AC), 254 V AC (440 V AC), 277 V AC (480 V AC), 3 W + (N) ^c + PE
Maximum output voltage at long-term operation	See standards a	bout the local po	ower grid.		
Rated output current	52.5 A (220 V AC) 28.9 A (400 V AC)	43.2 A (400 V AC) 36.0 A (480 V AC)	45.6 A (380 V AC) 43.3 A (400 V AC) 39.4 A (440 V AC) 36.1 A (480 V AC)	54.7 A (380 V AC) 52.0 A (400 V AC) 47.3 A (440 V AC) 43.3 A (480 V AC)	60.8 A (380 V AC) 57.8 A (400 V AC) 52.5 A (440 V AC) 48.1 A (480 V AC)
Maximum output current	58.0 A (220 V AC) 31.9 A (400 V AC)	43.2 A (400 V AC) 36.0 A (480 V AC)	50.4 A (380 V AC) 47.9 A (400 V AC) 43.5 A (440 V AC) 39.9 A (480 V AC)	61.1 A (380 V AC) 58.0 A (400 V AC) 52.8 A (440 V AC) (Mexico) 48.4 A (480 V AC)	67.2 A (380 V AC) 63.8 A (400 V AC) 58.0 A (440 V AC) (Mexico) 53.2 A (480 V AC)
Output voltage frequency	50 Hz/60 Hz				
Power factor	0.8 leading-0.8 lagging				
Output DC component DCI	< 0.5% of the ra	ated output			

Technical	SUN2000-20K	SUN2000-29.	SUN2000-30K	SUN2000-36K	SUN2000-40K
Specifications	TL-M3	9KTL-M3	TL-M3	TL-M3	TL-M3
Maximum total harmonic distortion (THD) AC THDi	< 3% under rate	ed conditions. Sir	ngle harmonic me	eets the VDE4105	requirements.

Note a: Under the Germany VDE-AR-N-4105, Belgium C10/11, and Austria TOR grid codes, the maximum apparent power and the maximum active power ($\cos\Phi$ =1) of the SUN2000-30KTL-M3 are 30,000 VA and 30,000 W respectively.

Note b: The rated output voltage is determined by **Grid code**, which can be set on the SUN2000 app, SmartLogger, or NMS.

Note c: You can determine whether to connect the neutral wire to the SUN2000-110KTL-M0, SUN2000-100KTL-M0, SUN2000-100KTL-M1, SUN2000-100KTL-INM0, or SUN2000-75KTL-M1 based on the application scenario. If no neutral wire is used, set **Output mode** to **Three-phase three-wire**. If the neutral wire is used, set the **Output mode** to **Three-phase four-wire**.

Protection

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3
Overvoltage category	PV II/AC III				
Input DC switch	Supported				
Islanding protection	Supported				
Output overcurrent protection	Supported				
Input reverse connection protection	Supported				
String fault detection	Supported				
DC surge protection	Type II				
AC surge protection	Type II				

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3
Insulation resistance detection	Supported				
Residual current monitoring unit (RCMU)	Supported				

Display and Communication

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3			
Display	LED indicator; V	LED indicator; WLAN+app						
RS485	Supported	Supported						
Built-in WLAN	Supported	Supported						
AC MBUS		This function is stact your vendor.	supported in spec	ified spare parts	models only.			
DC MBUS	Supported							
AFCI	Supported							
PID	Supported							

General Specifications

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3		
Dimensions (W x H x D)	640 mm x 530 ı	640 mm x 530 mm x 270 mm					
Net Weight	43 kg	43 kg					
Operating temperature	-25°C to +60°C	-25°C to +60°C (derated when the temperature is above +45°C)					
Humidity	0%-100%						
Cooling mode	Natural cooling						
Maximum operating altitude	0-4000 m						

10 Technical Specifications

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3	
Storage temperature	-40°C to +70°C					
IP rating	IP66					
Topology	Transformerless					

Wireless Communication Parameters

Specifications	Inverter Built- in WiFi	WLAN-FE Smart Dongle	4G Smart Dongle
Frequency	2400-2483.5	SDongleA-05:	SDongleA-03-CN:
	MHz	2400-2483.5	• Supports LTE-FDD: B1/B3/B8.
		MHz	• Supports LTE-TDD: B38/B39/B40/B41.
			• Supports DC-HSPA+/HSPA+/HSPA/ UMTS: B1/B5/B8/B9.
			• Supports TD-SCDMA: B34/B39.
			Supports GSM/GPRS/EDGE: 900 MHz/ 1800 MHz.
			SDongleA-03-EU:
			• Supports LTE-FDD: B1/B3/B7/B8/B20.
			Supports LTE-TDD: B38/B40.
			• Supports WCDMA/HSDPA/HSUPA/ HSPA+: B1/B8.
			Supports GSM/GPRS/EDGE: 900 MHz/ 1800 MHz.
			SDongleB-06-CN (WiFi): 2400–2483.5 MHz
			SDongleB-06-CN (4G):
			• Supports LTE-FDD: B1/B3/B5/B8.
			• Supports LTE-TDD: B34/B38/B39/B40/ B41.
			Supports GSM/GPRS/EDGE: 900 MHz/ 1800 MHz.
			SDongleB-06-EU (WiFi): 2400–2483.5 MHz
			SDongleB-06-EU (4G):
			• Supports LTE-FDD: B1/B3/B5/B8.
			• Supports LTE-TDD: B7/B20/B28/B38/B40/B41.
			Supports GSM/GPRS/EDGE: 900 MHz/ 1800 MHz.
			SDongleB-06-AU (WiFi): 2400–2483.5 MHz
			SDongleB-06-AU (4G):
			• LTE-FDD: B1/B2/B3/B4/B5/B7/B8/B28
			LTE-TDD: B40
			• WCDMA: B1/B2/B5/B8
			• GSM: 850 MHz/900 MHz/1800 MHz/ 1900 MHz

B1/B2/B3/B4/B5/B7/B8/B28/B66

Hse	r N/	lan	เเล

Specifications	Inverter Built- in WiFi	WLAN-FE Smart Dongle	4G Smart Dongle
			 Supports LTE-TDD (with receive diversity): B40 Supports WCDMA: B1/B2/B4/B5/B8
			 Supports WCDMA: B1/B2/B4/B3/B8 Supports GSM: 850/900/1800/1900 MHz
			Supports digital audio.

Specifications	Inverter Built- in WiFi	WLAN-FE Smart Dongle	4G Smart Dongle
Bandwidth	in WiFi 20 MHz/40 MHz (optional)	Dongle 20 MHz/40 MHz (optional)	LTE features: Supports a maximum of 3GPP R8 non-CA Cat 4 FDD and TDD. Supports 1.4 MHz/3 MHz/5 MHz/10 MHz/15 MHz/20 MHz RF bandwidth. Supports MIMO in the downlink. LTE-FDD: maximum downlink rate of 150 Mbit/s and maximum uplink rate of 50 Mbit/s LTE-TDD: maximum downlink rate of 130 Mbit/s and maximum uplink rate of 30 Mbit/s UMTS features: Supports 3GPP R7 HSDPA+, HSDPA, HSUPA, and WCDMA. Supports QPSK and 16QAM modulation. HSDPA+: maximum downlink rate of 21 Mbit/s HSUPA: maximum uplink rate of 5.76 Mbit/s WCDMA: maximum downlink rate of 384 kbit/s and maximum uplink rate of 384 kbit/s GSM features: GPRS: Supports GPRS multislot class 12. Coding schemes: CS-1, CS-2, CS-3, and CS-4 Maximum downlink rate: 85.6 kbit/s; maximum uplink rate: 85.6 kbit/s
			 Supports EDGE mutastot class 12. Supports GMSK and 8-PSK modulation and coding schemes.
			Downlink coding format: MCS 1–9
			Uplink coding format: MCS 1–9
			 Maximum downlink rate: 236.8 kbit/s; maximum uplink rate: 236.8 kbit/s

Specifications	Inverter Built- in WiFi	WLAN-FE Smart Dongle	4G Smart Dongle
Maximum transmit power	≤ 20 dBm EIRP	≤ 20 dBm EIRP	Class 4 (33 dBm±2 dB), EGSM900 frequency band
			Class 1 (30 dBm±2 dB), DCS1800 frequency band
			 Class E2 (27 dBm±3 dB), EGSM900 8- PSK
			 Class E2 (26 dBm±3 dB), DCS1800 8- PSK
			 Class 3 (24 dBm+1/-3 dB), WCDMA frequency band
			 Class 3 (23 dBm±2 dB), LTE-FDD frequency band
			Class 3 (23 dBm±2 dB), LTE-TDD frequency band



□ NOTE

The grid codes are subject to change. The listed codes are for reference only.

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
1	VDE-AR- N-4105	Germany low-voltage (LV) power grid	-	-	Supporte d	Supporte d	Supporte d
2	NB/T 32004	China LV power grid	-	-	Supporte d	Supporte d	Supporte d
3	UTE C 15-712-1(A)	France mainland power grid	-	-	Supporte d	Supporte d	Supporte d
4	UTE C 15-712-1(B)	France island power grid	-	-	Supporte d	Supporte d	Supporte d
5	UTE C 15-712-1(C)	France island power grid	-	-	Supporte d	Supporte d	Supporte d
6	VDE 0126-1-1-BU	Bulgaria power grid	-	-	Supporte d	Supporte d	Supporte d
7	VDE 0126-1-1- GR(A)	Greece mainland power grid	-	-	Supporte d	Supporte d	Supporte d
8	VDE 0126-1-1- GR(B)	Greece island power grid	-	-	Supporte d	Supporte d	Supporte d

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
9	BDEW-MV	Germany medium- voltage (MV) power grid	-	-	Supporte d	Supporte d	Supporte d
10	G59-England	England 230 V power grid (I > 16 A)	-	-	Supporte d	Supporte d	Supporte d
11	G59-Scotland	Scotland 240 V power grid (I > 16 A)	-	-	Supporte d	Supporte d	Supporte d
12	G83-England	England 230 V power grid (I < 16 A)	-	-	Supporte d	Supporte d	Supporte d
13	G83-Scotland	Scotland 240 V power grid (I < 16 A)	-	-	Supporte d	Supporte d	Supporte d
14	CEI0-21	Italy power grid	-	-	Supporte d	Supporte d	Supporte d
15	EN50438-CZ	Czech Republic power grid	-	-	Supporte d	Supporte d	Supporte d
16	RD1699/661	Spain LV power grid	-	-	Supporte d	Supporte d	Supporte d
17	RD1699/661- MV480	Spain MV power grid	-	-	Supporte d	Supporte d	Supporte d
18	EN50438-NL	Netherlands power grid	-	-	Supporte d	Supporte d	Supporte d
19	C10/11	Belgium power grid	-	-	Supporte d	Supporte d	Supporte d
20	AS4777	Australia power grid	-	Supporte d	Supporte d	Supporte d	Supporte d
21	AS4777- MV480	Australia MV power grid	-	Supporte d	Supporte d	Supporte d	Supporte d
22	AUSTRALIA- NER	Australia NER standard power grid	-	Supporte d	Supporte d	Supporte d	Supporte d

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
23	AUSTRALIA- NER-MV480	Australia NER standard power grid	-	Supporte d	Supporte d	Supporte d	Supporte d
24	AS4777-WP	Australia power grid	-	Supporte d	Supporte d	Supporte d	Supporte d
25	AS4777_ACT	Australia power grid	-	Supporte d	-	Supporte d	Supporte d
26	AS4777_NSW _ESS	Australia power grid	-	Supporte d	-	Supporte d	Supporte d
27	AS4777_NSW _AG	Australia power grid	-	Supporte d	-	Supporte d	Supporte d
28	AS4777_QLD	Australia power grid	-	Supporte d	-	Supporte d	Supporte d
29	AS4777_SA	Australia power grid	-	Supporte d	-	Supporte d	Supporte d
30	AS4777_VIC	Australia power grid	-	Supporte d	-	Supporte d	Supporte d
31	AUSTRALIA- AS4777_A- LV230	Australia power grid	-	Supporte d	-	Supporte d	Supporte d
32	AUSTRALIA- AS4777_B- LV230	Australia power grid	-	Supporte d	-	Supporte d	Supporte d
33	AUSTRALIA- AS4777_C- LV230	Australia power grid	-	Supporte d	-	Supporte d	Supporte d
34	AUSTRALIA- AS4777_NZ- LV230	Australia power grid	-	Supporte d	-	Supporte d	Supporte d
35	IEC61727	IEC 61727 LV grid- connection (50 Hz)	Supporte d	-	Supporte d	Supporte d	Supporte d
36	Custom (50 Hz)	Reserved	-	-	Supporte d	Supporte d	Supporte d
37	Custom (60 Hz)	Reserved	-	-	Supporte d	Supporte d	Supporte d

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
38	CEI0-16	Italy power grid	-	-	Supporte d	Supporte d	Supporte d
39	CHINA- MV480	China MV power grid	-	-	Supporte d	Supporte d	Supporte d
40	CHINA-MV	China MV power grid	-	-	Supporte d	Supporte d	Supporte d
41	TAI-PEA	Thailand grid- connection standard	-	-	Supporte d	Supporte d	Supporte d
42	TAI-MEA	Thailand grid- connection standard	-	-	Supporte d	Supporte d	Supporte d
43	BDEW-MV480	Germany MV power grid	-	-	Supporte d	Supporte d	Supporte d
44	Custom MV480 (50 Hz)	Reserved	-	-	Supporte d	Supporte d	Supporte d
45	Custom MV480 (60 Hz)	Reserved	-	-	Supporte d	Supporte d	Supporte d
46	G59-England- MV480	UK 480 V MV grid- connection (I > 16 A)	-	-	Supporte d	Supporte d	Supporte d
47	IEC61727- MV480	IEC 61727 MV grid- connection (50 Hz)	-	-	Supporte d	Supporte d	Supporte d
48	UTE C 15-712-1- MV480	France island power grid	-	-	Supporte d	Supporte d	Supporte d
49	TAI-PEA- MV480	Thailand MV grid- connection (PEA)	-	-	Supporte d	Supporte d	Supporte d

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
50	TAI-MEA- MV480	Thailand MV grid- connection (MEA)	-	-	Supporte d	Supporte d	Supporte d
51	EN50438-DK- MV480	Denmark MV grid- connection	-	-	Supporte d	Supporte d	Supporte d
52	EN50438-TR- MV480	Turkey MV power grid	-	-	Supporte d	Supporte d	Supporte d
53	EN50438-TR	Turkey LV power grid	-	-	Supporte d	Supporte d	Supporte d
54	C11/C10- MV480	Belgium MV power grid	-	-	Supporte d	Supporte d	Supporte d
55	Philippines	Philippines LV power grid	-	-	Supporte d	Supporte d	Supporte d
56	Philippines- MV480	Philippines MV power grid	-	-	Supporte d	Supporte d	Supporte d
57	NRS-097-2-1	South Africa power grid standard	-	-	Supporte d	Supporte d	Supporte d
58	NRS-097-2-1- MV480	South Africa MV power grid	-	-	Supporte d	Supporte d	Supporte d
59	KOREA	South Korea power grid	-	-	Supporte d	Supporte d	Supporte d
60	IEEE 1547- MV480	IEEE 1547- MV480	-	-	Supporte d	Supporte d	Supporte d
61	IEC61727-60H z	IEC 61727 LV grid- connection (60 Hz)	-	-	Supporte d	Supporte d	Supporte d
62	IEC61727-60H z-MV480	IEC 61727 MV grid- connection (60 Hz)	-	-	Supporte d	Supporte d	Supporte d
63	CHINA_MV50 0	China MV power grid	-	-	Supporte d	Supporte d	Supporte d

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
64	ANRE	Romania LV power grid	-	-	Supporte d	Supporte d	Supporte d
65	PO12.3- MV480	Spain MV power grid	-	-	Supporte d	Supporte d	Supporte d
66	EN50438_IE- MV480	Ireland MV power grid	-	-	Supporte d	Supporte d	Supporte d
67	EN50438_IE	Ireland LV power grid	-	-	Supporte d	Supporte d	Supporte d
68	IEC61727-50H z-MV500	India 500 V MV power grid	-	-	Supporte d	Supporte d	Supporte d
69	CEI0-16- MV480	Italy MV power grid	-	-	Supporte d	Supporte d	Supporte d
70	PO12.3	Spain LV power grid	-	-	Supporte d	Supporte d	Supporte d
71	CEI0-21- MV480	Italy MV power grid	-	-	Supporte d	Supporte d	Supporte d
72	KOREA- MV480	South Korea MV power grid	-	-	Supporte d	Supporte d	Supporte d
73	Egypt ETEC	Egypt LV power grid	-	-	Supporte d	Supporte d	Supporte d
74	Egypt ETEC- MV480	Egypt MV power grid	-	-	Supporte d	Supporte d	Supporte d
75	EN50549-LV	Ireland power grid	-	-	Supporte d	Supporte d	Supporte d
76	EN50549- MV480	Ireland MV power grid	-	-	Supporte d	Supporte d	Supporte d
77	Jordan- Transmission	Jordan LV power grid	-	-	Supporte d	Supporte d	Supporte d
78	Jordan- Transmission- MV480	Jordan MV power grid	-	-	Supporte d	Supporte d	Supporte d
79	NAMIBIA	Namibia power grid	-	-	Supporte d	Supporte d	Supporte d
80	ABNT NBR 16149	Brazil power grid	-	-	Supporte d	Supporte d	Supporte d

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
81	ABNT NBR 16149-MV480	Brazil MV power grid	-	-	Supporte d	Supporte d	Supporte d
82	SA_RPPs	South Africa LV power grid	-	-	Supporte d	Supporte d	Supporte d
83	SA_RPPs- MV480	South Africa MV power grid	-	-	Supporte d	Supporte d	Supporte d
84	INDIA	India LV power grid	-	-	Supporte d	Supporte d	Supporte d
85	INDIA-MV500	India MV power grid	-	-	Supporte d	Supporte d	Supporte d
86	ZAMBIA	Zambia LV power grid	-	-	Supporte d	Supporte d	Supporte d
87	ZAMBIA- MV480	Zambia MV power grid	-	-	Supporte d	Supporte d	Supporte d
88	Chile	Chile LV power grid	-	-	Supporte d	Supporte d	Supporte d
89	Chile-MV480	Chile MV power grid	-	-	Supporte d	Supporte d	Supporte d
90	Mexico- MV480	Mexico MV power grid	-	-	Supporte d	Supporte d	Supporte d
91	Malaysian	Malaysia LV power grid	-	-	Supporte d	Supporte d	Supporte d
92	Malaysian- MV480	Malaysia MV power grid	-	-	Supporte d	Supporte d	Supporte d
93	KENYA_ETHIO PIA	Kenya LV power grid and Ethiopia power grid	-	-	Supporte d	Supporte d	Supporte d
94	KENYA_ETHIO PIA-MV480	Kenya LV power grid and Ethiopia MV power grid	-	-	Supporte d	Supporte d	Supporte d
95	NIGERIA	Nigeria LV power grid	-	-	Supporte d	Supporte d	Supporte d

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
96	NIGERIA- MV480	Nigeria MV power grid	-	-	Supporte d	Supporte d	Supporte d
97	DUBAI	Dubai LV power grid	-	-	Supporte d	Supporte d	Supporte d
98	DUBAI- MV480	Dubai MV power grid	-	-	Supporte d	Supporte d	Supporte d
99	Northern Ireland	Northern Ireland LV power grid	-	-	Supporte d	Supporte d	Supporte d
100	Northern Ireland- MV480	Northern Ireland MV power grid	-	-	Supporte d	Supporte d	Supporte d
101	Cameroon	Cameroon LV power grid	-	-	Supporte d	Supporte d	Supporte d
102	Cameroon- MV480	Cameroon MV power grid	-	-	Supporte d	Supporte d	Supporte d
103	Jordan- Distribution	Jordan LV distribution power grid	-	-	Supporte d	Supporte d	Supporte d
104	Jordan- Distribution- MV480	Jordan MV distribution power grid	-	-	Supporte d	Supporte d	Supporte d
105	NAMIBIA_MV 480	Namibia power grid	-	-	Supporte d	Supporte d	Supporte d
106	LEBANON	Lebanon LV power grid	-	-	Supporte d	Supporte d	Supporte d
107	LEBANON- MV480	Lebanon MV power grid	-	-	Supporte d	Supporte d	Supporte d
108	ARGENTINA- MV500	Argentina MV power grid	-	-	Supporte d	Supporte d	Supporte d
109	Jordan- Transmission- HV	Jordan high- voltage (HV) power grid	-	-	Supporte d	Supporte d	Supporte d
110	Jordan- Transmission- HV480	Jordan HV power grid	-	-	Supporte d	Supporte d	Supporte d

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
111	TUNISIA	Tunisia power grid	-	-	Supporte d	Supporte d	Supporte d
112	TUNISIA- MV480	Tunisia MV power grid	-	-	Supporte d	Supporte d	Supporte d
113	SAUDI	Saudi Arabia power grid	-	-	Supporte d	Supporte d	Supporte d
114	SAUDI- MV480	Saudi Arabia power grid	-	-	Supporte d	Supporte d	Supporte d
115	Ghana- MV480	Ghana MV power grid	-	-	Supporte d	Supporte d	Supporte d
116	Israel	Israel power grid	-	-	Supporte d	Supporte d	Supporte d
117	Israel-MV400	Israel power grid	-		Supporte d	Supporte d	Supporte d
118	Israel-MV480	Israel power grid	-	-	Supporte d	Supporte d	Supporte d
119	Chile-PMGD	Chile PMGD power grid	-	-	Supporte d	Supporte d	Supporte d
120	Chile-PMGD- MV480	Chile PMGD power grid	-	-	Supporte d	Supporte d	Supporte d
121	VDE-AR- N4120-HV	VDE 4120 standard power grid	-	-	Supporte d	Supporte d	Supporte d
122	VDE-AR- N4120-HV480	VDE 4120 standard power grid	-	-	Supporte d	Supporte d	Supporte d
123	CHINA- LV220/380	China LV power grid	-	-	Supporte d	Supporte d	Supporte d
124	Vietnam	Vietnam	-	-	Supporte d	Supporte d	Supporte d
125	Vietnam- MV480	Vietnam	-	-	Supporte d	Supporte d	Supporte d
126	TAIPOWER	Taiwan Power LV power grid	-	-	Supporte d	Supporte d	Supporte d

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
127	TAIPOWER- MV480	Taiwan Power MV power grid (480 V)	-	-	Supporte d	Supporte d	Supporte d
128	ARGENTINA- MV480	Argentina MV power grid	-	-	Supporte d	Supporte d	Supporte d
129	OMAN	Oman LV power grid	-	-	Supporte d	Supporte d	Supporte d
130	OMAN- MV480	Oman MV power grid	-	-	Supporte d	Supporte d	Supporte d
131	KUWAIT	Kuwait LV power grid	-	-	Supporte d	Supporte d	Supporte d
132	KUWAIT- MV480	Kuwait MV power grid	-	-	Supporte d	Supporte d	Supporte d
133	BANGLADESH	Bangladesh LV power grid	-	-	Supporte d	Supporte d	Supporte d
134	BANGLADESH -MV480	Bangladesh MV power grid	-	-	Supporte d	Supporte d	Supporte d
135	Chile- Net_Billing	Chile Net Billing power grid	-	-	Supporte d	Supporte d	Supporte d
136	EN50438-NL- MV480	Netherlands MV power grid	-	-	Supporte d	Supporte d	Supporte d
137	BAHRAIN	Bahrain LV power grid	-	-	Supporte d	Supporte d	Supporte d
138	BAHRAIN- MV480	Bahrain MV power grid	-	-	Supporte d	Supporte d	Supporte d
139	Fuel_Engine_ Grid	Diesel generator hybrid power grid	-	-	Supporte d	Supporte d	Supporte d
140	Fuel-Engine- Grid-60Hz	Diesel generator hybrid power grid	-	-	Supporte d	Supporte d	Supporte d

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
141	ARGENTINA	Argentina power grid	-	-	Supporte d	Supporte d	Supporte d
142	Mauritius	Mauritius power grid	-	-	Supporte d	Supporte d	Supporte d
143	Mauritius- MV480	Mauritius MV power grid	-	-	Supporte d	Supporte d	Supporte d
144	EN50438-SE	Sweden LV power grid	-	-	Supporte d	Supporte d	Supporte d
145	Pakistan	Pakistan power grid	-	-	Supporte d	Supporte d	Supporte d
146	Austria	Austria power grid	-	-	Supporte d	Supporte d	Supporte d
147	Austria- MV480	Austria MV power grid	-	-	Supporte d	Supporte d	Supporte d
148	G99-TYPEA- LV	UK G99- TYPEA-LV power grid	-	-	Supporte d	Supporte d	Supporte d
149	G99-TYPEB- LV	UK G99- TYPEB-LV power grid	-	-	Supporte d	Supporte d	Supporte d
150	G99-TYPEB- HV	UK G99- TYPEB-HV power grid	-	-	Supporte d	Supporte d	Supporte d
151	G99-TYPEB- HV-MV480	UK G99- TYPEB-HV MV power grid	-	-	Supporte d	Supporte d	Supporte d
152	G99-TYPEA- HV	UK G99- TYPEA-HV power grid	-	-	Supporte d	Supporte d	Supporte d
153	EN50549- MV400	Ireland new standard	-	-	Supporte d	Supporte d	Supporte d
154	VDE-AR- N4110	Germany MV power grid (230 V)	-	-	Supporte d	Supporte d	Supporte d
155	VDE-AR- N4110- MV480	Germany MV power grid	-	-	Supporte d	Supporte d	Supporte d

User Manual A Grid Codes


No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
156	NTS	Spain power grid	-	-	Supporte d	Supporte d	Supporte d
157	NTS-MV480	Spain MV power grid	-	-	Supporte d	Supporte d	Supporte d
158	CEA	India CEA LV power grid	-	-	Supporte d	Supporte d	Supporte d
159	CEA-MV480	India CEA MV power grid	-	-	Supporte d	Supporte d	Supporte d
160	SINGAPORE	Singapore LV power grid	-	-	Supporte d	Supporte d	Supporte d
161	SINGAPORE- MV480	Singapore MV power grid	-	-	Supporte d	Supporte d	Supporte d
162	HONGKONG	Hong Kong LV power grid	-	-	Supporte d	Supporte d	Supporte d
163	HONGKONG- MV480	Hong Kong MV power grid	-	-	Supporte d	Supporte d	Supporte d
164	C10/11- MV400	Belgium MV power grid	-	-	Supporte d	Supporte d	Supporte d
165	EN50549-SE	Sweden LV power grid	-	-	Supporte d	Supporte d	Supporte d
166	EN50549-PL	Poland power grid	-	-	Supporte d	Supporte d	Supporte d
167	DANMARK- EN50549- DK1-LV230	Denmark power grid	-	-	Supporte d	Supporte d	Supporte d
168	DANMARK- EN50549- DK2-LV230	Denmark power grid	-	-	Supporte d	Supporte d	Supporte d
169	SWITZERLAN D-LV230	Switzerland power grid	-	-	Supporte d	Supporte d	Supporte d
170	ABNT NBR 16149-LV127	Brazil LV power grid	Supporte d	-	-	-	-
171	Mexico-LV220	Mexico LV power grid	Supporte d	-	-	-	-


User Manual A Grid Codes

No.	Grid Code	Description	SUN2000 -20KTL- M3	SUN2000 -29.9KTL- M3	SUN2000 -30KTL- M3	SUN2000 -36KTL- M3	SUN2000 -40KTL- M3
172	Philippines- LV220-50Hz	Philippines LV power grid (50 Hz)	Supporte d	-	-	-	-
173	Philippines- LV220-60Hz	Philippines LV power grid (60 Hz)	Supporte d	-	-	-	-
174	TAIPOWER- LV220	Taiwan Power LV power grid	Supporte d	-	-	-	-

B Device Commissioning

Step 1 Access **Device commissioning** screen.





User Manual




Figure B-2 Method 2: after login (connected to the Internet)

Step 2 Connect to the solar inverter WLAN and log in to the device commissioning screen as the **installer** user.

NOTICE

- When connecting to the SUN2000 directly from the mobile phone, keep the
 mobile phone visible within 3 meters of the SUN2000 to ensure the
 communication quality between the app and SUN2000. The distances are for
 reference only and may vary with mobile phones and shielding conditions.
- When connecting the SUN2000 to the WLAN over a router, ensure that the mobile phone and SUN2000 are in the WLAN coverage of the router and the SUN2000 is connected to the router.
- The router supports WLAN (IEEE 802.11 b/g/n, 2.4 GHz) and the WLAN signal reaches the SUN2000.
- The WPA, WPA2, or WPA/WPA2 encryption mode is recommended for routers. Enterprise-level encryption is not supported (for example, public hotspots requiring authentication such as airport WLAN). WEP and WPA TKIP are not recommended because these two encryption modes have serious security defects. If the access fails in WEP mode, log in to the router and change the encryption mode of the router to WPA2 or WPA/WPA2.

Ⅲ NOTE

- Obtain the initial password for connecting to the solar inverter WLAN from the label on the side of the solar inverter.
- Use the initial password upon first power-on and change it immediately after login. To
 ensure account security, change the password periodically and keep the new password
 in mind. Not changing the initial password may cause password disclosure. A password
 left unchanged for a long period of time may be stolen or cracked. If a password is lost,
 devices cannot be accessed. In these cases, the user is liable for any loss caused to the
 PV plant.
- When you access the **Device commissioning** screen of the SUN2000 for the first time, you need to manually set the login password because the SUN2000 does not have an initial login password.




NOTICE

Ensure that the inverter ground cable is securely connected. Otherwise, the built-in PID repair function will be affected and electric shocks may occur.

Procedure

Step 1 On the home screen, choose **Settings** > **Feature Parameters** and set related parameters.

Figure C-1 Setting PID suppression parameters



■ NOTE

- Set PID running mode to Repair (disabled by default).
- Set **Nighttime off-grid repair** to (this parameter is displayed when **Built-in PID** running mode is set to **Repair**).

User Manual D Rapid Shutdown

Rapid Shutdown

If all PV modules are equipped with optimizers, the PV system can perform a rapid shutdown, reducing the output voltage of the optimizers to below 30 V within 30s. The rapid shutdown is not supported if optimizers are configured for some PV modules.

Triggering methods of rapid shutdown:

- Method 1 (recommended): Turn off the AC switch between the inverter and the power grid.
- Method 2: Turn off the DC switch at the bottom of the inverter.
- Method 3: If the DIN5 port (port 15) of the inverter communications terminal is connected to a rapid shutdown button, press the button to trigger rapid shutdown.

MOTE

Log in to the FusionSolar App as an installer, choose **Me** > **Device Commissioning**, and connect to the WLAN hotspot of the SUN2000. Log in to the local commissioning system as an installer user, choose **Settings** > **Feature parameters** > **Dry contact function**, and set **Dry contact function** to **DI rapid shutdown**.

• Method 4: If **AFCI** is enabled, the inverter automatically detects arc faults, triggering a rapid shutdown.

User Manual E NS Protection




Connecting the Inverter to the NS Protection Signal Cable

□ NOTE

- The NS protection function applies to areas in compliance with the VDE4105 standard, and the grid code needs to be set to VDE-AR-N-4105.
- The NS protection switch is connected to GND (pin 13) at one end and to DIN5 (pin 15) at the other end. The switch is turned off by default. When the switch is turned on, NS protection is triggered.
- Rapid shutdown and NS protection use the same pins, which are GND (pin 13) and DIN5 (pin 15). Therefore, you can use only one of the functions.
- The NS protection switch connection is the same for a single inverter and for cascaded inverters.
- Log in to the FusionSolar App as an installer, choose Me > Device Commissioning, and connect to the WLAN hotspot of the SUN2000. Log in to the local commissioning system as an installer user, choose Settings > Feature parameters > Dry contact function, and set Dry contact function to NS protection.

Figure E-1 Connecting cascaded inverters to the NS protection switch



User Manual F Resetting Password

Resetting Password

- **Step 1** Check that the AC and DC power supplies to the solar inverter are connected simultaneously, and that the and ▶ indicators are steady green or blink slowly for more than 3 minutes.
- **Step 2** Turn off the AC switch, set the DC switch at the bottom of the solar inverter to OFF, and wait until all indicators on the solar inverter panel turn off.
- **Step 3** Complete the following operations within 3 minutes:
 - 1. Turn on the AC switch and wait until the > indicator blinks.
 - 2. Turn off the AC switch and wait until all indicators on the solar inverter panel turn off.
 - 3. Turn on the AC switch and wait until all LED indicators on the inverter panel blink and turn off after about 30s.
- **Step 4** Wait until the three indicators on the inverter panel blink green quickly and then blink red quickly, indicating that the password has been restored.
- **Step 5** Reset the password within 10 minutes. (If no operation is performed within 10 minutes, all parameters of the solar inverter remain the same as those before the reset.)
 - 1. Wait until the > indicator blinks.
 - 2. Obtain the initial WLAN hotspot name (SSID) and initial password (PSW) from the label on the side of the solar inverter to connect to the app.
 - 3. On the login page, set a new login password and log in to the app.
- **Step 6** Set router and management system parameters to implement remote management.

----End

NOTICE

You are advised to reset the password in the morning or at night when the solar irradiance is low.




G Setting Dry Contact Scheduling **Parameters**

Procedure

User Manual

Step 1 On the home screen, choose Settings > Power adjustment and set Dry contact scheduling to .

Figure G-1 Setting dry contact scheduling parameters



User Manual H AFCI



Function

If PV modules or cables are not properly connected or damaged, electric arcs may occur, which may cause fire. Huawei SUN2000s provide unique arc detection in compliance with UL 1699B-2018 to ensure the safety of users' lives and property.

This function is enabled by default. The SUN2000 automatically detects arc faults. To disable this function, log in to the FusionSolar App, enter the **Device**Commissioning screen, choose Settings > Feature parameters, and disable AFCI.

Ⅲ NOTE

The AFCI function works only with Huawei optimizers or ordinary PV modules, but does not support third-party optimizers or intelligent PV modules.

Clearing Alarms

The AFCI function involves the **DC arc fault** alarm.

The SUN2000 has the AFCI alarm automatic clearance mechanism. If an alarm is triggered for less than five times within 24 hours, the SUN2000 automatically clears the alarm. If the alarm is triggered for five times or more within 24 hours, the SUN2000 locks for protection. You need to manually clear the alarm on the SUN2000 so that it can work properly.


You can manually clear the alarm as follows:

• Method 1: FusionSolar App

Log in to the FusionSolar App and choose **Me > Device commissioning**. On the **Device commissioning** screen, connect and log in to the SUN2000 that generates the AFCI alarm, tap **Alarm management**, and tap **Clear** on the right of the **DC arc fault** alarm to clear the alarm.

User Manual H AFCI

Figure H-1 Alarm management



Method 2: FusionSolar Smart PV Management System
 Log in to the FusionSolar Smart PV Management System using a non-owner

account, choose **Maintenance** > **Alarm Management**, select the **DC arc fault** alarm, and click **Clear** to clear the alarm.

Figure H-2 Clearing alarms



Switch to the owner account with PV plant management rights. On the home page, click the PV plant name to go to the PV plant page, and click **OK** as prompted to clear the alarm.

PV String Access Detection


Description

- PV string access detection applies to large-scale commercial and utility-scale
 PV plants with PV strings facing the same direction.
- In AC or DC power limiting scenarios:
 - If the PV access type is not identified, the PV status will be displayed as Not connected. The PV string access type can be identified only when the inverters restore to the non-power limiting state and the current of all connected PV strings reaches Startup current.
 - After setting parameters, you can view the string access status on the Running Info screen.

Procedure

- **Step 1** Log in to the FusionSolar app and choose **Me > Device commissioning**. The **Device commissioning** screen is displayed.
- **Step 2** Choose **Maintenance** > **PV string access detection**. The parameter setting screen is displayed.

Figure I-1 PV string access detection




No.	Parameter	Description	Remarks
1	PV string access detection	PV string access detection is set to Disable by default. After the inverter connects to the power grid properly, set this parameter to Enable .	-
2	Startup current	When the current of all connected PV strings reaches the preset value, the PV string access detection function is enabled. NOTE Startup current setting rules: • Startup current = I _{sc} (S _{tc}) x 0.6 (rounded up). For details about I _{sc} (S _{tc}), see the PV module nameplate. • Default startup current (5 A): applicable to the scenarios where the short-circuit current I _{sc} (S _{tc}) is greater than 8 A for the monocrystalline and polycrystalline PV modules.	This parameter is displayed when PV string access detection is set to Enable.
3	Startup current for 2-in-1 detection	When the current of a PV string reaches Startup current for 2-in-1 detection , the PV string is automatically identified as 2-in-1. The default value is recommended.	

No.	Parameter	Description	Remarks
4	PV string N access type NOTE N is the DC input terminal number of the inverter.	Set this parameter based on the type of the PV string connected to DC input terminal N of the inverter. Currently, the options are as follows: Automatic identification (default value), Disconnection, Single PV string, and 2-in-1. The default value is recommended. If the value is incorrectly set, the PV string access type may be incorrectly identified and false alarms may be generated for the PV string access status.	

Smart I-V Curve Diagnosis

For details, see SmartPVMS Smart I-V Curve Diagnosis User Manual.



If the ground impedance of a PV string connected to the inverter is too low, the inverter generates a **Low insulation resistance** alarm.

The possible causes are as follows:

- A short circuit has occurred between the PV array and the ground.
- The ambient air of the PV array is damp and the insulation between the PV array and the ground is poor.

After the **Low insulation resistance** alarm is reported by the inverter, insulation resistance fault location is automatically triggered. If the fault location is successful, the location information is displayed on the **Alarm details** screen of the **Low insulation resistance** alarm on the FusionSolar app.

Log in to the FusionSolar app, choose **Alarm > Active alarm**, select **Low insulation resistance** to enter the **Alarm details** screen.


Figure K-1 Alarm details



□ NOTE

- The positive and negative terminals of a PV string are respectively connected to the PV+ and PV- terminals of the inverter. The PV- terminal represents a possibility of 0% for the short-circuit position and the PV+ terminal represents a possibility of 100% for the short-circuit position. Other percentages indicate that the fault occurs on a PV module or cable in the PV string.
- Possible fault position = Total number of PV modules in a PV string x Percentage of possible short-circuit positions. For example, if a PV string consists of 14 PV modules and the percentage of the possible short-circuit position is 34%, the possible fault position is 4.76 (14 x 34%), indicating that the fault is located near PV module 4, including the previous and the next PV modules and the cables. The inverter has a detection precision of ±1 PV module.
- The possible faulty PV string MPPT1 corresponds to PV1 and PV2, and the possible faulty PV string MPPT2 corresponds to PV3 and PV4. The fault can be located only to the MPPT level. Perform the following steps to connect the PV strings corresponding to the faulty MPPT to the inverter one by one to further locate and rectify the fault.
- When a non-short-circuit fault occurs, the possible short-circuit percentage is not displayed. If the insulation resistance is greater than 0.001 $M\Omega$, the fault is not related to short circuit. Check all PV modules in the faulty PV string one by one to locate and rectify the fault.

Figure K-2 Percentage of short-circuit positions



Procedure

NOTICE

If the irradiance or the PV string voltage is too high, the insulation resistance fault location may fail. In this case, the fault location status on the **Alarm details** screen is **Conditions not met**. Perform the following steps to connect PV strings to the inverter one by one to locate the fault. If the system is not configured with any optimizer, skip the corresponding optimizer operations.

- **Step 1** Ensure that the AC connections are normal. Log in to the FusionSolar app, choose **Maintenance** > **Inverter ON/OFF** on the home screen, and send a shutdown command. Set **DC SWITCH** to **OFF**.
- **Step 2** Connect one PV string to the inverter, and set **DC SWITCH** to **ON**. If the inverter status is **Shutdown: Command**, log in to the app, choose **Maintenance** > **Inverter ON/OFF** on the home screen, and send a startup command.
- **Step 3** Choose **Alarm** on the home screen, enter the **Active alarm** screen, and check whether a **Low insulation resistance** alarm is reported.

- If no Low insulation resistance alarm is reported 1 minute after the DC side is powered on, choose Maintenance > Inverter ON/OFF on the home screen, and send a shutdown command. Set DC SWITCH to OFF. Go to Step 2 and check rest of the PV strings one by one.
- If a **Low insulation resistance** alarm is reported 1 minute after the DC side is powered on, check the percentage of possible short-circuit positions on the **Alarm details** screen and calculate the location of the possible faulty PV module based on the percentage. Then go to **Step 4**.
- Step 4 Log in to the app, choose Maintenance > Inverter ON/OFF on the home screen, and send a shutdown command. Set DC SWITCH to OFF. Check whether the connectors or DC power cables between the optimizer and PV module, between adjacent PV modules, or between adjacent optimizers on the possible fault position are damaged.
 - If yes, replace the damaged connectors or DC power cables, and then set DC SWITCH to ON. If the inverter status is Shutdown: Command, choose Maintenance > Inverter ON/OFF, and send a startup command. View alarm information.
 - If no Low insulation resistance alarm is reported 1 minute after the DC side is powered on, troubleshoot the insulation resistance fault of the PV string. Log in to the app, choose Maintenance > Inverter ON/OFF on the home screen, and send a shutdown command. Set DC SWITCH to OFF.
 Go to Step 2 and check rest of the PV strings one by one. Then, go to Step 8.
 - If the DC side is powered on 1 minute later, the Low insulation resistance alarm is still reported. Log in to the app, choose Maintenance > Inverter ON/OFF on the home screen, and send a shutdown command. Set DC SWITCH to OFF and go to Step 5.
 - If no, go to Step 5.
- Step 5 Disconnect the possible faulty PV module and the paired optimizer from the PV string, and use a DC extension cable with an MC4 connector to connect the PV module or optimizer adjacent to the possible faulty PV module. Set DC SWITCH to ON. If the inverter status is Shutdown: Command, choose Maintenance > Inverter ON/OFF on the home screen, and send a startup command. View alarm information.
 - If no Low insulation resistance alarm is reported 1 minute after the DC side is powered on, the fault occurred on the disconnected PV module and optimizer. Choose Maintenance > Inverter ON/OFF, send a shutdown command, and set DC SWITCH to OFF. Go to Step 7.
 - If the **Low insulation resistance** alarm is reported 1 minute after the DC side is powered on, the fault did not occur on the disconnected PV module and optimizer. Go to **Step 6**.
- Step 6 Log in to the app, choose Maintenance > Inverter ON/OFF on the home screen, and send a shutdown command. Set DC SWITCH to OFF, reconnect the disconnected PV module and optimizer, and repeat Step 5 to check the PV modules and optimizers adjacent to the possible fault location.
- **Step 7** Determine the position of the ground insulation fault:
 - Disconnect the possible faulty PV module from the optimizer.

- Connect the possible faulty optimizer to the PV string.
- Set DC SWITCH to ON. If the inverter status is Shutdown: Command, choose Maintenance > Inverter ON/OFF, and send a startup command. View alarm information.
 - If no Low insulation resistance alarm is reported 1 minute after the DC side is powered on, the fault is on the possible faulty PV module.
 - If the Low insulation resistance alarm is reported 1 minute after the DC side is powered on, the fault is on the possible faulty optimizer.
- Log in to the app, choose Maintenance > Inverter ON/OFF on the home screen, and send a shutdown command. Set DC SWITCH to OFF, replace the faulty component, and complete troubleshooting the insulation resistance fault. Go to Step 2 and check rest of the PV strings one by one. Then, go to Step 8.
- **Step 8** Set **DC SWITCH** to **ON**. If the inverter status is **Shutdown: Command**, choose **Maintenance** > **Inverter ON/OFF**, and send a startup command.

User Manual L Contact Information

Contact Information

If you have any questions about this product, please contact us.



https://digitalpower.huawei.com

Path: About Us > Contact Us > Service Hotlines

To ensure faster and better services, we kindly request your assistance in providing the following information:

- Model
- Serial number (SN)
- Software version
- Alarm ID or name
- Brief description of the fault symptom

User Manual L Contact Information

◯ NOTE

EU Representative Information: Huawei Technologies Hungary Kft. Add.: HU-1133 Budapest, Váci út 116-118., 1. Building, 6. floor.

Email: hungary.reception@huawei.com

Digital Power Customer Service



https://digitalpower.huawei.com/robotchat/

Acronyms and Abbreviations

Α

AFCI arc-fault circuit interrupter

L

LED light emitting diode

М

MBUS monitoring bus

MPP maximum power point

MPPT maximum power point tracking

Ρ

PE protective earthing

PID potential induced degradation

PV photovoltaic

R

RCD residual current device