sun2000-10ктL-вем1 Quick Guide

Issue: 01 Part Number: 31500JKB Date: 2023-07-30

HUAWEI


HUAWEI TECHNOLOGIES CO., LTD.

NOTICE

1. The information in this document is subject to change due to version upgrades or other reasons. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied. You can download this document by scanning the QR code.




- 2. Before installing the device, read the user manual carefully to get familiar with product information and safety precautions.
- 3. Only gualified and trained electrical technicians are allowed to operate the device. Operation personnel should understand the composition and working principles of the grid-tied PV power system and local regulations.
- 4. Before installing the device, check that the package contents are intact and complete against the packing list. If any damage is found or any component is missing, contact your dealer.
- 5. Use insulating tools when installing the device. For personal safety, wear proper personal protective equipment (PPE).
- 6. Huawei shall not be liable for any consequences caused by the violation of the storage, transportation, installation, and operation regulations specified in this document and the user manual.



rights reserved.

2 Installing the Equipment

2.1 Installation Requirements



D NOTE

Two M6 screw holes are reserved on both left and right sides of the inverter for installing an awning.


2.2 Installing the Inverter

When drilling holes, avoid the water pipes and power cables buried in the wall.

1. Install the mounting bracket.

D NOTE

- M6x60 expansion bolts are delivered with the inverter. If the length and number of the bolts
 do not meet installation requirements, prepare M6 stainless steel expansion bolts by yourself.
- The expansion bolts delivered with the inverter are used for solid concrete walls. For other types of walls, prepare bolts by yourself and ensure that the wall meets the load bearing requirements of the inverter.
- Loosen the nuts, flat washers, and spring washers of the two expansion bolts.




2. (Optional) Install the screw for locking the DC switch.

IS10H00003

IS10H00034

D NOTE

- The screws for DC switches are delivered with solar inverters. According to Australian standards, the screws are used to secure DC switches (DC SWITCH) to prevent them from being turned on by mistake.
- For the model used in Australia, perform this step to meet the local standards.



Prepare an anti-theft lock suitable for the lock hole diameter ($\Phi 8$ mm) and ensure that the lock can be installed successfully. An outdoor waterproof lock is recommended.

IS10H00033

3 Electrical Connections

3.1 Preparing for Installation

- Do not connect loads between the inverter and the AC switch that directly connects to the inverter. Otherwise, the switch may trip by mistake.
- If an AC switch is used with specifications beyond local standards, regulations, or Huawei's
 recommendations, the switch may fail to turn off in a timely manner in case of exceptions,
 causing serious faults.

Each inverter must be equipped with an AC output switch. Multiple inverters cannot connect to the same AC output switch.

NOTICE

- To ensure that the inverter can be safely disconnected from the power grid when an exception occurs, connect an AC switch to the AC side of the inverter. Select an appropriate AC switch in accordance with local industry standards and regulations.
- Cable specifications must meet the requirements in local standards. Electrical connections must meet the requirements in the relevant regulations of the country or region.
- Before connecting cables, ensure that the DC SWITCH on the inverter and all the switches connected to the inverter are set to OFF. Otherwise, the high voltage of the inverter may result in electric shocks.

No.	Item	Туре	Specifications
1	PE cable	Single-core outdoor copper cable	Conductor cross-sectional area ≥ 4 mm ²
2	AC output power cable	Outdoor copper cable	 Conductor cross-sectional area: 4– 6 mm² Cable outer diameter: 10–21 mm
3	DC input power cable and (optional) battery cable	Standard outdoor PV cable in the industry (recommended model: PV1-F)	 Conductor cross-sectional area: 4– 6 mm² Cable outer diameter: 5.5–9 mm
4	(Optional) RS485 communications cable (used to cascade inverters or connect to the RS485 signal port on the SmartLogger)	Two-core outdoor shielded twisted pair cable	 Conductor cross-sectional area: 0.2–1 mm² Cable outer diameter: 4–11 mm Note: When devices such as the
5	(Optional) RS485 communications cable (used to connect to the RS485 signal port on devices such as the Smart Power Sensor and the energy storage device)		Smart Power Sensor and the energy storage device are both connected to the inverter, use 0.2–0.5 mm ² cords.
6	(Optional) Rapid shutdown switch signal cable		
7	(Optional) Grid scheduling signal cable		
8	(Optional) Grid scheduling signal cable	Five-core outdoor cable	

No.	ltem	Туре	Specifications
9	AC switch	Recommended: three- phase AC circuit breaker	Rated voltage ≥ 380 V AC Rated current: • 16 A (3KTL-6KTL) • 25 A (8KTL-10KTL)

3.2 Installing the PE Cable

A DANGER

Do not connect the neutral wire to the enclosure as a PE cable. Otherwise, electric shocks may occur.



D NOTE

- The PE point at the AC output port is used only as a PE equipotential point, and cannot substitute for the PE point on the enclosure.
- It is recommended that silica gel or paint be used around the ground terminal after the PE cable is connected.


3.3 Installing the AC Output Power Cable

NOTICE

Ensure that the protection layer of the AC output power cable is inside the connector, the core wires are totally inserted into the cable hole, and the cable is connected securely. Failing to do so may cause device malfunction or damage.

1. Connect the AC output power cable to the AC connector.

Stripping Requirements








IS06I20048

Five-Core Cable (L1, L2, L3, N, and PE)


D NOTE


- This section describes how to connect a five-core AC output power cable to an AC connector.
- A three-core AC output power cable can be connected similarly. The three-core cable (L1, L2, and L3) is not connected to the neutral wire or PE wire.
- A four-core or five-core AC output power cable can be connected similarly. The four-core cable (L1, L2, L3, and PE) is not connected to the N wire, and the four-core cable (L1, L2, L3, and N) is not connected to the PE wire.




2. Connect the AC connector to the AC output port.

IS10I20001






3. Check the route of the AC output power cable.




3.4 Installing the DC Input Power Cable

NOTICE

- 1. Ensure that the PV module output is well insulated to ground.
- 2. Use the Staubli MC4 positive and negative metal terminals and DC connectors supplied with the solar inverter. Using incompatible positive and negative metal terminals and DC connectors may result in serious consequences. The caused device damage is not covered under warranty.
- 3. The DC input voltage of the SUN2000 shall not exceed 1100 V DC under any circumstance.
- 4. Before installing the DC input power cable, label the cable polarities to ensure correct cable connections.
- 5. If the DC input power cable is reversely connected, do not operate the DC switch as well as positive and negative connectors immediately. Failing to do so may cause device damage, which is not covered under any warranty. Wait until the night when solar irradiance declines and the PV string current drops to below 0.5 A. Then set the DC switch to the OFF position, remove the positive and negative connectors, and correct the polarities of the DC input power cable.
- 6. If the PV strings are configured with Smart PV Optimizers, refer to the Smart PV Optimizer Quick Guide to check the cable polarity.
- 1. Assemble DC connectors.



2. Connect DC input power cables.




IH07I30002


3.5 (Optional) Installing Battery Cables

- Use insulated tools when connecting cables.
- Connect battery cables with correct polarity. If battery cables are reversely connected, the solar inverter may be damaged.

Assemble the positive and negative connectors by following the instructions in section 3.4 "Installing DC Input Power Cables."



Battery terminals (BAT+/BAT-)




IH07I30003

3.6 Installing the Smart Dongle

D NOTE

- If FE communication is used, install a WLAN-FE Smart Dongle (SDongleA-05). The WLAN-FE Smart Dongle is delivered with the SUN2000.
- If 4G communication is used, install a 4G Smart Dongle (SDongleA-03). You need to purchase the 4G Smart Dongle by yourself.

Smart Dongle port (GPRS/4G/WLAN-FE)



D NOTE


- For details about how to operate the WLAN-FE Smart Dongle SDongleA-05, see SDongleA-05 Smart Dongle Quick Guide (WLAN-FE).
- For details about how to operate the 4G Smart Dongle SDongleA-03, see *SDongleA-03 Quick Guide (4G)*.
- The quick guide is delivered with the Smart Dongle. You can download them by scanning the QR code below.





WLAN-FE Smart Dongle (FE Communication)


You are advised to use a CAT 5E outdoor shielded network cable (outer diameter < 9 mm; internal resistance \leq 1.5 Ω /10 m) and shielded RJ45 connectors.



(Optional) 4G Smart Dongle (4G Communication)

NOTICE

- If your Smart Dongle is not equipped with a SIM card, prepare a standard SIM card (size: 25 mm x 15 mm) with the capacity greater than or equal to 64 KB.
- Install the SIM card in the arrow direction.
- When reinstalling the cover of the Smart Dongle, ensure that the buckle springs back in place (you can hear a click).




IS10H00016

3.7 (Optional) Installing the Signal Cable

NOTICE

- Not all inverter models are delivered with the signal cable connector.
- When laying out the signal cable, separate it from the power cable and keep it away from strong interference sources to avoid strong communication interference.
- Ensure that the protection layer of the cable is inside the connector, surplus core wires are cut off from the protection layer, the exposed core wire is totally inserted into the cable hole, and that the cable is connected securely.
- If the Smart Dongle is configured, you are advised to install the Smart Dongle before connecting the signal cable.

Communications Port Pin Definition




D NOTE

- When the RS485 communications cables of devices such as the Smart Power Sensor and the energy storage device are both connected to the inverter, 485A2 (pin 7), 485B2 (pin 9), and PE (pin 5) are shared.
- When the enable signal cable of the energy storage device and the signal cable of the rapid shutdown switch are both connected to the inverter, GND (pin 13) is shared.


Pin	Definition	Function	Description	Pin	Definition	Function	Description
1	485A1-1	RS485A, RS485 differential signal+	Used to cascade inverters or connect to the	2	485A1-2	RS485A, RS485 differential signal+	Used to cascade inverters or connect to the
3	485B1-1	RS485B, RS485 differential signal–	RS485 signal port on the SmartLogger	4	485B1-2	RS485B, RS485 differential signal–	RS485 signal port on the SmartLogger
5	PE	Shielding ground	N/A	6	PE	Shielding ground	N/A
7	485A2	RS485A, RS485 differential signal+	Used to connect to the RS485	8	DIN1	Digital input signal 1+	Used to connect to dry contacts for grid scheduling or serve as a port for the feedback signal of the Backup Box.
9	485B2	RS485B, RS485 differential	signal port on devices such as the Smart Power Sensor and the energy				
		signal–	storage device	10	DIN2	Digital input signal 2+	
11	EN	Enabling signal	Used to connect to the enable signal port on an energy storage device	12	DIN3	Digital input signal 3+	Dry contact for grid scheduling
13	GND	GND	Used to connect to the rapid shutdown DI	14	DIN4	Digital input signal 4+	
15	DIN5	Rapid shutdown signal+	signal port or serve as a port for the signal cable of the NS protection.	16	GND	GND of DIN1/DIN2 /DIN3/DIN 4	Used to connect to the GND of DIN1/DIN2/DIN3/ DIN4

Smart Dongle Networking Scenario



- In the Smart Dongle networking scenario, the SmartLogger cannot be connected.
- The Smart Power Sensor is necessary for export limitation. Select the Smart Power Sensor according to the actual project.
- A maximum of 10 devices can be connected to the WLAN-FE and 4G Smart Dongles. The Smart Power Sensors connected to the RS485A2 and RS485B2 ports are not included.
- If a battery is connected, a maximum of three inverters can be cascaded. Any one of the inverters can be connected to the battery. (The inverter connected to the Smart Dongle must be connected to the battery.)
- If the SUN2000-(3KTL-10KTL)-M1 Series and SUN2000-(2KTL-6KTL)-L1 are cascaded, a maximum of three inverters can be cascaded.

SmartLogger Networking Scenario




D NOTE


- In the SmartLogger networking scenario, the Smart Dongle cannot be connected.
- A maximum of 80 devices can connect to a single SmartLogger, such as inverters, Smart Power sensor, and EMI. You are advised to connect fewer than 30 devices to each RS485 route.
- The Smart Power Sensor is necessary for export limitation. Select the Smart Power Sensor according to the actual project.
- To ensure the system response speed, you can connect the Smart Power Sensor to a separate COM port.

(Optional) Installing the RS485 Communications Cable (Inverter Cascading)

1. Connect the signal cable to the signal cable connector.




2. Connect the signal cable connector to the communication port.




IS10I20007

(Optional) Installing the RS485 Communications Cable (Only Smart Power Sensor Connected)

1. Connect the signal cable to the signal cable connector.




2. Connect the signal cable connector to the communication port.




(Optional) Installing the RS485 Communications Cable (Smart Power Sensor and Energy Storage Device Connected)

1. Connect the signal cable to the signal cable connector.




2. Connect the signal cable connector to the Communication port.






(Optional) Installing the Grid Scheduling Dry Contact Signal Cable

1. Connect the signal cable to the signal cable connector.




IS10I20010

2. Connect the signal cable connector to the Communication port.




(Optional) Installing Signal Cables for a Smart Backup Box

1. Connect the signal cable to the signal cable connector.



IS10I20018

2. Connect the signal cable connector to the Communication port.




4 Verifying Installation

No.	Acceptance Criteria
1	The inverter is installed correctly and securely.
2	Cables are routed properly as required by the customer.
3	The Smart Dongle is installed correctly and securely.
4	Cable ties are evenly distributed and no burr exists.
5	The PE cable is connected correctly, securely, and reliably.
6	The DC switch and all the switches connected to the inverter are set to the OFF position.
7	The AC output power cable, DC input power cable, battery cable, and signal cable are connected correctly and securely.
8	Unused terminals and ports are locked by watertight caps.
9	The installation space is proper, and the installation environment is clean and tidy.

5 Powering On the System

NOTICE

- Before turning on the AC switch between the solar inverter and the power grid, check that the AC voltage is within the specified range using a multimeter set to the AC position.
- If the solar inverter is connected to an LG battery, turn on the DC switch within 1 minute after turning on the AC switch. If you turn on the DC switch after more than 1 minute, the solar inverter will shut down and start again.
- 1. If a battery is connected, turn on the battery switch.
- 2. Turn on the AC switch between the solar inverter and the power grid.
- 3. (Optional) Remove the screw for locking the DC switch.



- 4. Turn on the DC switch (if any) between the PV string and the solar inverter.
- 5. Turn on the DC switch at the bottom of the solar inverter.

6. Observe the LEDs to check the operating status of the inverter.

Туре	for 1s and th	nen Off for 1: rvals: On for		Meaning	
Running indication]	l∼ C	N/A	
	Steady gree	n Steady g	green	The solar inverter is operating in grid-tied mode.	
	Blinking gre at long intervals	en Off		The DC is on and the AC is off.	
	Blinking gre at long intervals	en Blinking long int	green at ervals	Both the DC and AC are on, and the solar inverter is not exporting power to the power grid.	
	Off	Blinking long int	green at ervals	The DC is off and the AC is on.	
	Off	Off		Both the DC and AC are off.	
	Blinking red short interva			There is a DC environmental alarm, such as an alarm indicating that High String Input Voltage, String Reverse Connection, or Low Insulation Resistance.	
	N/A	Blinking short in		There is an AC environmental alarm, such as an alarm indicating Grid Undervoltage, Grid Overvoltage, Grid Overfrequency, or Grid Underfrequency.	
	Steady red	Steady ı	red	Fault.	
Communication indication	(m) O			N/A	
	Blinking green at short intervals			Communication is in progress.	
	Blinking green at long intervals			A mobile phone is connected to the solar inverter.	
	Off			There is no communication.	
Device replacement indication]∼ O	(I) (I)	N/A	
	Steady red	Steady red	Steady red	The solar inverter hardware is faulty. The solar inverter needs to be replaced.	

7. (Optional) Observe the LED to check the operating status of the Smart Dongle.

WLAN-FE Smart Dongle

		_
		LE
	FRONT	
C)

	LED		Description	
	Color	Status		
	Yellow (blinking green and red simultaneously)	Steady on	The Dongle is secured and powered on.	
ED	Red	Blinking at short intervals (on for 0.2s and then off for 0.2s)	The parameters for connecting to the router are to be set.	
	Green	Blinking at long intervals (on for 0.5s and then off for 0.5s)	Connecting to the router	
	Green	Steady on	Successfully connected to the management system.	
	Green	Blinking at short intervals (on for 0.2s and then off for 0.2s)	The inverter is communicating with the management system through the Dongle.	

4G Smart Dongle

	D		Description
Colo	or	Status	
gree	ow (blinking en and red ultaneously)	Steady on	The Dongle is secured and powered on.
Gree		Blinking in a 2-second cycle (on for 0.1s and then off for 1.9s)	Dialing (duration < 1 min)
Gree		5 5	The dial-up connection is set up successfully (duration < 30s).
Gree	en	5	Successfully connected to the management system.
Gree		intervals (on for 0.2s and	The inverter is communicating with the management system through the Dongle.

6 Commissioning

D NOTE

- The screenshots are for reference only. The actual screens may vary.
- Obtain the initial password for connecting to the solar inverter WLAN from the label on the side of the solar inverter.
- To ensure account security, change the password periodically and keep the new password in mind. Not changing the password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.
- Before maintaining the optimizers and PV strings, turn off the AC switch and set the DC switch to OFF. Otherwise, the PV strings may be energized, resulting in electric shocks.

6.1 Downloading the App

Method 1: Search for FusionSolar on Huawei AppGallery and download the latest installation package.

Method 2: Access https://solar.huawei.com using the mobile phone browser and download the latest installation package.



Method 3: Scan the following QR code and download the latest installation package.




6.2 (Optional) Registering an Installer Account

D NOTE

If you already have an installer account, skip this step.

Creating the first installer account will generate a domain named after the company.



Plants Statistics		<	Add user	
🐺 Setup wizard	d user	*Company		XXX
Q. Enter a plant name.	7	*Role ⑦		Installer
XXXXX		*Plant Ass	ociation	> 🕀
•		*Username	e	
10.00kWp 0.00kWh	kWh	*Password	i	77
		Photo		3
		*Country/F	Region code	
		*Phone		
		Email		
	e	I have	obtained the owner's	authorization.
🍐 🙆 🖽	0	If the conter information,	nt you entered involves obtain authorization in	third-party personal advance.
Home Maintenance Devices	Me	Caper		Saw

NOTICE

To create multiple installer accounts for a company, log in to the FusionSolar app and tap **Add user** to create an installer account.

6.3 Creating a PV Plant and a Plant Owner



- In the quick settings, the grid code is set to N/A by default (automatic startup is not supported). Set the grid code based on the area where the PV plant is located.
- For details, see the *FusionSolar App Quick Guide.* You can scan the QR code to download the quick guide.



6.4 Setting the Physical Layout of Smart PV Optimizers


- If Smart PV Optimizers are configured for PV strings, ensure that the Smart PV Optimizers have been successfully connected to the solar inverter before performing the operations in this section.
- The PV strings connecting to the same MPPT route should contain the same number and model of PV modules or Smart PV optimizers.
- Check that the SN labels of Smart PV Optimizers are correctly attached to the physical layout template.
- Take and save a photo of the physical layout template. Place the template on a flat surface. Keep your phone parallel to the template and take a photo in landscape mode. Ensure that the four positioning points in the corners are in the frame. Ensure that each QR code is attached within the frame.
- For details about the physical layout of Smart PV Optimizers, see *FusionSolar App Quick Guide*.

Scenario 1: Setting on the FusionSolar Server Side (Solar Inverter Connected to the Management System)

1. Tap the plant name on the **Home** screen to access the plant screen. Select **Layout**, tap and upload the physical layout template photo of the PV plant as prompted.




 Log in to https://intl.fusionsolar.huawei.com to access the WebUI of the FusionSolar Smart PV Management System. On the Home page, click the plant name to go to the plant page. Select Layout. Choose Generate Layout, and create a physical layout as prompted. You can also manually create a physical layout.




D NOTE

You can also upload the physical layout template photo on the WebUI as follows: Log in to https://intl.fusionsolar.huawei.com to access the WebUI of the FusionSolar Smart PV Management System. On the **Home** page, click the plant name to go to the plant page. Select **Layout**. Choose **Click to Upload**, and upload the physical layout template photo.



Scenario 2: Setting on the Solar Inverter Side (Solar Inverter Not Connected to the Management System)

- 1. If the solar inverter is not connected to the FusionSolar Smart PV Management System, access the **Device commissioning** screen (Refer to 7.1 Device Commissioning.) on the FusionSolar app to set the physical layout of Smart PV Optimizers.
 - a. Log in to the FusionSolar app. On the **Device commissioning** screen, choose **Maintenance** > **Optimizer layout**. The **Optimizer layout** screen is displayed.
 - b. Tap the blank area. The **Identify image** and **Add PV modules** buttons are displayed. You can use either of the following methods to perform operations as prompted:
 - Method 1: Tap Identify image and upload the physical layout template photo to complete the optimizer layout. (The optimizers that fail to be identified need to be manually bound.)
 - Method 2: Tap Add PV modules to manually add PV modules and bind the optimizers to the PV modules.



D NOTE

For details about the physical layout of optimizers on the FusionSolar app and FusionSolar WebUI, see the *FusionSolar App Quick Guide*. You can scan the QR code to download the quick guide.



6.5 Setting Battery Parameters

D NOTE

If the solar inverter connects to batteries, set battery parameters.

- Log in to the FusionSolar app and choose My > Device commissioning. The Device commissioning screen (Refer to 7.1 Device Commissioning.) is displayed.
- Choose Power adjustment > Battery control and set battery parameters, including Charge from grid, Control mode (Fully fed to grid, TOU(Time-of-use), Maximum self-consumption), and so on.

6.6 SmartLogger Networking Scenario

For details, see the *PV Plants Connecting to Huawei Hosting Cloud Quick Guide (Inverters + SmartLogger3000 + RS485 Networking).* You can scan the QR codes to obtain the documents.



>

Battery control

7 FAQ

7.1 Device Commissioning

1. Access Device commissioning.

Scenario 1: Your phone is not connected to the Internet.



Cancel

Scenario 2: Your phone is connected to the Internet.



<

Working mode

Maximum charge power

Maximum discharge

End-of-charge capacity

2. Connect to the solar inverter WLAN and log in as **installer** to access the device commissioning screen.

< ···	C Identity authentication		D-XXX-XX
		Remain Annual Communications component	Connection failed
	**	Active power 0.000(ww	Energy yield of current day
Corpect		Monthly Energy Yield 0.030we	Total 4.64(uan)
(Manual connection		D Alarm	Quick settings
Connection record	Enter vour password	Device Monitoring	Maintenance
	Frank San Kananan	کې Settings	Power adjustment
No connection record	Cancel Log in		Concession and a second

7.2 Resetting the Password

- 1. Ensure that the SUN2000 connects to the AC and DC power supplies at the same time. Indicators ≒ and a re steady green or blinking slowly for more than 3 minutes.
- 2. Perform the following operations within 4 minutes:
 - a. Turn off the AC switch and set the DC SWITCH at the bottom of the SUN2000 to OFF. If the SUN2000 connects to batteries, turn off the battery switch. Wait until all the LED indicators on the SUN2000 panel turn off.
 - b. Turn on the AC switch, set the DC SWITCH to ON, and wait for about 90s. Ensure that the indicator \mathbb{I}^{\sim} is blinking green slowly.
 - c. Turn off the AC switch and set the DC SWITCH to OFF. Wait until all LED indicators on the SUN2000 panel turn off.
 - d. Turn on the AC switch and set the DC SWITCH to ON. Wait until all indicators on the SUN2000 panel blink and turn off 30 seconds later.
- 3. Reset the password within 10 minutes. (If no operation is performed within 10 minutes, all inverter parameters remain unchanged.)
 - a. Wait until the indicator J~ blinks green slowly.
 - b. Obtain the initial WLAN hotspot name (SSID) and initial password (PSW) from the label on the side of the SUN2000 and connect to the SUN2000 on the app.
 - c. On the login screen, set a new login password and log in to the app.
- 4. Set router and management system parameters to implement remote management.

8 Installation Video

D NOTE

You can scan the QR code below to obtain the installation video.



9 Customer Service Contact

Customer Serv	vice Contact			
Region	Country	Service Support Email	Phone	
	France			
	Germany			
	Spain	eu inverter support@huawei.com	0080033888888	
Europe	Italy		0000033000000	
	UK			
	Netherlands			
	Other countries	For details, see <u>solar.huawei.com</u> .	1	
	Australia	eu_inverter_support@huawei.com	1800046639	
	Turkey	eu_inverter_support@huawei.com	N/A	
	Malaysia	_	0080021686868 /1800220036	
Asia Pacific	Theilend	apsupport@huawei.com	(+66) 26542662 (charged by local call)	
	Thailand		1800290055 (free in Thailand)	
	China	solarservice@huawei.com	400-822-9999	
	Other countries	apsupport@huawei.com	0060-3-21686868	
Japan	Japan	solarsupportjp@huawei.com	0120258367	
India	India	indiaenterprise_TAC@huawei.com	1800 103 8009	
Republic of Korea	Republic of Korea	koreainverter@huawei.com	N/A	
North	USA	eu_inverter_support@huawei.com	1-877-948-2934	
America	Canada	eu_inverter_support@huawei.com	1-855-482-9343	
	Mexico		018007703456 /0052-442-4288288	
	Argentina		0-8009993456	
Latin America	Brazil	la_inverter_support@huawei.com	0-8005953456	
	Chile		800201866 (only for fixed)	
	Other countries		0052-442-4288288	
	Egypt		08002229000 /0020235353900	
	UAE	-	08002229000	
Middle East	South Africa		0800222900	
and Africa	Saudi Arabia	eu_inverter_support@huawei.com	8001161177	
	Pakistan	-	0092512800019	
	Morocco	-	0800009900	
	Other countries		0020235353900	

Huawei Technologies Co., Ltd. Huawei Industrial Base, Bantian, Longgang Shenzhen 518129 People's Republic of China solar.huawei.com