# SUN2000-(196KTL-H0, 200KTL-H2, 215KTL-H0)

# **Quick Guide**

Issue: 14

Part Number: 31500CPW


Date: 2022-01-20



#### NOTICE

- The information in this document is subject to change without notice. Every effort has been
  made in the preparation of this document to ensure accuracy of the contents, but all
  statements, information, and recommendations in this document do not constitute a warranty
  of any kind, express or implied.
- Only qualified and trained electrical technicians are allowed to operate the device. Operators should understand the composition and working principles of the grid-tied PV power system and local standards.
- Before installing the device, read the user manual carefully to get familiar with product information and safety precautions. Huawei shall not be liable for any consequences caused by the violation of the storage, transportation, installation, and operation regulations specified in this document and the user manual.
- Use insulated tools when installing the device. For personal safety, wear proper personal protective equipment (PPE).






**◯** NOTE

The DC switch of the current model can be manual or automatic.


#### Port Illustration (Manual DC Switch)



- (1) DC input terminals (controlled by DC SWITCH 1)
- (3) DC input terminals (controlled by DC SWITCH 2)
- (5) DC input terminals (controlled by DC SWITCH 3)
- (7) Ventilation valve
- (9) Communications port (COM)
- (11) Hole for the tracking system power cable

- (2) DC switch 1 (DC SWITCH 1)
- (4) DC switch 2 (DC SWITCH 2)
- (6) DC switch 3 (DC SWITCH 3)
- (8) USB port (USB)
- (10) Hole for the AC output power cable

#### Port Illustration (Automatic DC Switch)



- (1) DC input terminals (controlled by DC SWITCH 1) (2) DC switch 1<sup>[1]</sup> (DC SWITCH 1)
- (3) Reset button 1 (RESET 1)
- (5) DC switch 2<sup>[1]</sup> (DC SWITCH 2)
- (7) DC input terminals (controlled by DC SWITCH 3) (8) DC switch 3[1] (DC SWITCH 3)
- (9) Reset button 3 (RESET 3)
- (11) USB port (USB)
- (13) Hole for the AC output power cable

- (4) DC input terminals (controlled by DC SWITCH 2)
- (6) Reset button 2 (RESET 2)
- (10) Ventilation valve
- (12) Communications port (COM)
- (14) Hole for the tracking system power cable


## DC Switch Description

#### **⚠** DANGER


The DC switches automatically turn off when a fault occurs in the inverters (LED4 is steady red, and the three DC switches are OFF). In this case, contact your technical support. Do not turn on the DC switches by yourself.

Switch Component	Description	
DC SWITCH	ON	The DC switch is ON and can automatically turn off for protection.
	<u> </u>	The DC switch is ON but cannot automatically turn off for protection.
	OFF	The DC switch is OFF.
RESET	<ul> <li>When the DC switch automatically turns off for protection, the RESET but will be released.</li> <li>When the RESET button is not pressed, the DC switch can only be turned unloaded position will be released.</li> </ul>	

#### **SUN2000 Dimensions**



### **Mounting Bracket Dimensions**




# 2 Installation Requirements


#### NOTICE

If inverters are installed in a place with abundant vegetation, in addition to routine weeding, harden the ground underneath the inverters using cement or gravel (recommended area: 3 m x 2.5 m).

## 2.1 Installation Angle




# 2.2 Installation Space




# 3 Installing the SUN2000

#### □ NOTE


- The M12x40 bolt assemblies are delivered with the SUN2000 (bound to the mounting bracket). If the bolt assembly length does not meet the installation requirements, prepare M12 bolt assemblies by yourself and use them together with the delivered M12 nuts.
- Before installing the mounting bracket, remove the security Torx wrench from the mounting bracket and save it for later use.
- This document introduces how to install the SUN2000 on a support as an example. For details about wall-mounted installation, see the user manual.



### 1. Install the mounting bracket.



2. Unpack the inverter and move it to the specified position.




IS06H00101

### ☐ NOTE

Handles are packed in a fitting bag and are not delivered with the SUN2000.

3. Adjust the installation positions of the handles, and install the SUN2000 on the mounting bracket.



# 4 Installing Cables

# 4.1 Installation Preparations

### ☐ NOTE

If outdoor copper-core cables are used, select copper wiring terminals. For details about the requirements for cables and terminals of other materials, see the user manual.

No.	Item	Туре	Specifications	Description
1	PE cable	Single-core outdoor copper cable	Conductor cross- sectional area ≥ S/2 <sup>[1]</sup> (S is the conductor cross- sectional area of the AC output power cable.)	<ul> <li>If you choose the ground point on the chassis shell for connecting a PE cable, prepare the PE cable.</li> <li>If you choose the ground point in the maintenance compartment for connecting a PE cable, use a four-core AC output power cable and do not have to prepare a PE cable.</li> </ul>
2	AC output power cable <sup>[2][3][4]</sup>	Outdoor copper cable	Conductor cross-sectional area: 50–240 mm² Cable outer diameter: 24–66 mm (multicore); 14–32 mm (single-core)	If you choose the ground point in the maintenance compartment for connecting a PE cable, use a four-core cable. Otherwise, use a threecore cable or three
		Outdoor aluminum-core cable	Conductor cross-sectional area: 70–240 mm² (multicore); 70–240 mm² (single-core) Cable outer diameter: 24–66 mm (multicore); 14–32 mm (single-core)	single-core cables.
3	DC input power cable	PV cable that meets the 1500 V standard	Conductor cross- sectional area: 4-6 mm <sup>2</sup> Cable outer diameter: 4.7-6.4 mm	-

No.	Item	Туре	Specifications	Description
4	RS485 communication s cable	Outdoor shielded twisted pair cable	Conductor cross- sectional area: 0.25–1 mm²     Cable outer diameter: 4–11 mm	When three communications cables connect to the signal cable connector, the outer diameter of the cables should be 4–8 mm.
5	(Optional) Power cable of the tracking system	Three-core outdoor copper cable with dual-layer protection	Conductor cross- sectional area: 10 mm²     Cable outer diameter: 15–18 mm	-


Note [1]: The value is valid only if the conductors of the PE cable and AC power cable use the same material. If the materials are different, ensure that the conductor cross-sectional area of the PE cable produces a conductance equivalent to that of the area S/2. The specifications of the PE cable are subject to this table or calculated according to IEC 60364-5-54.

Note [2]: You are advised to use a soft cable to prevent poor terminal contact due to the bending stress of the cable.

Note [3]: For some models, the outer diameter of a single-core cable ranges from 14 mm to 36 mm based on the label in the maintenance compartment.

Note [4]: For some models, when the OT/DT terminal is crimped as shown in the following figure and the rubber baffle plate of the AC wiring terminal is 112 mm, the maximum conductor cross-sectional area of the single-core cable can be 400 mm<sup>2</sup>.

## Specifications of the Crimped OT/DT Terminal




IS06W00081

### 4.2 Installing the PE Cable

#### □ NOTE

- It is recommended that the PE cable be connected to a nearby PE point. Connect the PE points of all SUN2000s in the same PV array to ensure equipotential connections to PE cables.
- To enhance the corrosion resistance of a ground terminal, you are advised to apply silica gel or paint on it after connecting the PE cable.




IS06I20043

# 4.3 Opening the Maintenance Compartment Door

#### **♠** WARNING

- Do not open the host panel of the SUN2000.
- Before opening the SUN2000 maintenance compartment door, turn off the downstream AC output switch and three DC switches at the bottom.
- Do not open the maintenance compartment door in rainy or snowy days. If you must, take
  protective measures to prevent rain or snow from entering the maintenance compartment.
- Do not leave unused screws in the maintenance compartment.
- 1. Loosen the screws on the maintenance compartment door.
- Open the maintenance compartment door and adjust the support bar.




IS06I20040

3. Remove the crimping modules that are bound in the maintenance compartment and save them properly for future use.

#### □ NOTE


For some models, a three-hole rubber plug is bound in the maintenance compartment. After removing the rubber plug, save it properly for future use.



# 4.4 (Optional) Replacing the Crimping Module

#### **◯** NOTE

If the AC output power cable has a single core, replace the crimping module.




IS06I20047

### 4.5 Removing the Rubber Rings from the Crimping Module

#### □ NOTE

Use scissors to cut off the joints of the rubber rings to remove them. All rubber rings are removed in the same way.




IS06H00106

# 4.6 (Optional) Installing the Solar Tracker Power Cable

#### NOTICE


- A switch-disconnector-fuse or fuse-switch-disconnector with a voltage of no less than 800 V, current of 16 A, and protection type of gM needs to be installed between the SUN2000 and the tracker controller for protection.
- 2. The cable between the wiring terminal on the power cable and the switch-disconnector-fuse or fuse-switch-disconnector should be less than or equal to 2.5 meters.



# 4.7 Installing AC Output Power Cables

#### NOTICE

- Remove the corresponding rubber rings in strict accordance with the cable diameter, and ensure
  that the crimping module is not damaged. Otherwise the protection level of the solar inverter
  will be affected.
- Ensure that AC terminations provide firm and solid electrical connections. Failing to do so may cause SUN2000 malfunction and damage to its terminal block, even starting thermal events.
- If the AC output power cables are subject to a pulling force because the inverter is not installed stably, ensure that the last cable that bears the stress is the PE cable.



1506120041

# Single-core Cable ☐ NOTE The 32-36 mm cable is supported only 32-36 mm (five rings) by some models. Refer to the ■ 30-32 mm (four rings) corresponding label to get the 22-30 mm (three rings) supported size. 15-22 mm (two rings) ■ 14-15 mm (one ring) 0 2 3 4 5 6 8 IS06H00126 D: 15-22 mm D: 14-15 mm L +3 mm D: 22-30 mm D: 30-32 mm D: 32-36 mm M12 25-30 N·m


# **Bending Radius**

Multi-Core	Cable	Single-Core Cable		
Unarmored Armored		Unarmored	Armored	
R ≥ 15D	R ≥ 12D	R ≥ 20D	R ≥ 15D	

R indicates the bending radius, and D indicates the outer diameter of the cable.


#### **□** NOTE

The AC power cable must be routed vertically into the maintenance compartment.



IS06I20057

### 4.8 Closing the Maintenance Compartment Door



## 4.9 Installing DC Input Power Cables

### Wiring Description of Y-branch Connectors

#### NOTICE


- Y-branch connectors can be purchased from Huawei or the manufacturers based on the
  following recommended models: If the rated current of the fuse of the Y-branch connector is
  15 A, the recommended model is 904095944 (Luxshare) or A040959443039 (Comlink); if
  the rated current of the fuse of the Y-branch connector is 20 A, the recommended model is
  904095945 (Luxshare) or A040959453039 (Comlink).
- When connecting cables to recommended Y-branch connectors, ensure that the connectors
  to be paired match each other and are from the same manufacturer. Otherwise, the contact
  resistance of the connectors may exceed the allowed value. In this case, the connectors may
  be heated and oxidized, which may cause faults.
- Ensure that the locking nuts of all connectors are tightened.
- Do not bind more than three fuse enclosures together. Otherwise, the fuses and their
  enclosures may be damaged due to overheating. It is recommended that a clearance of 10
  mm or more be reserved between fuse enclosures. You are advised not to bind the fuse
  enclosures with other heat emitting conductors.

#### Wiring rules:

- 1. The PV+ on the string side must be connected to the PV+ on the SUN2000 side, and the PV- on the string side must be connected to the PV- on the SUN2000 side.
- Preferentially and evenly connect the Y-branch connectors to the MPPTs controlled by DC SWITCH 1 or DC SWITCH 2

Number of Y- branch Connector Sets	Recommended MPPT to Be Connected	Number of Y-branch Connector Sets	Recommended MPPT to Be Connected
1	MPPT1	2	MPPT1 and MPPT4
3	MPPT1, MPPT3 and MPPT4	4	MPPT1, MPPT3, MPPT4 and MPPT6
5	MPPT1, MPPT2, MPPT3, MPPT4, and MPPT5	6	MPPT1, MPPT2, MPPT3, MPPT4, MPPT5, and MPPT6
7	MPPT1, MPPT2, MPPT3, MPPT4, MPPT5, MPPT6, and MPPT7	8	MPPT1, MPPT2, MPPT3, MPPT4, MPPT5, MPPT6, MPPT7, and MPPT8
9	MPPT1, MPPT2, MPPT3, MPPT4, MPPT5, MPPT6, MPPT7, MPPT8, and MPPT9	N/A	N/A

# **Y-branch Connector Solution**




Scenario	Model of Y-branch Connector (Part A)	Connection Description	
Connecting Y- branch connectors to the PV strings (recommended)	ch connectors e PV strings All models Use the DC terminals delivered with the SU to connect part B to the SUN2000s.		
	Models recommended by Huawei	Part A can be directly connected to the SUN2000, and part B is not needed.	
Connecting Y- branch connectors to the SUN2000	Other models	To ensure that the terminals of part A match the DC terminals of the SUN2000, part B is needed to connect part A to the SUN2000. Use the DC terminals delivered with the SUN2000 to connect part B to the SUN2000.	


#### NOTICE

- It is recommended that the Y-branch connectors be connected from the PV string side and tied to the PV trackers.
- The DC input terminals of the solar inverter are prone to damage under stress. When Y-branch connectors are connected to the solar inverter, bind and secure the connectors to minimize stress on the DC input terminals.
- Do not place the Y-branch connector harness on the ground. A safe distance must be reserved between the Y-branch connector harness and the ground to avoid impact caused by water on the ground to the harness.

### Recommended tying solution:



# **Selecting DC Input Terminals**



IS06W00078

#### ☐ NOTE

The SUN2000 has three DC switches (DC SWITCH 1, DC SWITCH 2, and DC SWITCH 3). DC SWITCH 1 controls routes 1–6 of DC input terminals, DC SWITCH 2 routes 7–12, and DC SWITCH 3 routes 13–18.

Select DC input terminals according to the following rules:

- Evenly distribute the DC input power cables to the DC input terminals controlled by the three DC switches. DC SWITCH 1 is preferred.
- 2. Maximize the number of connected MPPT circuits.


#### **⚠** WARNING


Ensure that the PV module output is well insulated to ground.

#### NOTICE


- 1. Use the MC4 EVO2 PV connectors delivered with the SUN2000. If the PV connectors are lost or damaged, purchase the connectors of the same model. The device damage caused by incompatible PV connectors is beyond the warranty scope.
- 2. Before connecting DC input power cables, label the cable polarities to ensure correct cable connections. If the cables are connected incorrectly, the SUN2000 may be damaged.
- 3. Measure the voltage at the DC input end using a multimeter. If the voltage is a negative value, the DC input polarity is incorrect. Correct the polarity. If the voltage is greater than 1500 V, too many PV modules are configured to the same string. Remove some PV modules.
- 4. If polarity of the DC input power cable is reversed and the DC switch is ON, do not turn off the DC switch immediately or unplug positive and negative connectors. The device may be damaged if you do not follow the instruction. The caused equipment damage is beyond the warranty scope. Wait until the solar irradiance declines and the PV string current reduces to below 0.5 A, and then turn off the three DC switches and remove the positive and negative connectors. Correct the string polarity before reconnecting the string to the SUN2000.
- 5. For models of the crimping tool and removal wrench, use the recommended model or contact your Staubli dealer.
- 6. Connect the PV string connector to the inverter connector, and then pull back the PV string connector along the axial direction to check whether the connectors are securely connected.
- 7. The connector must be securely connected. Damages caused by improper connection are not covered under the warranty.


### **Installing a DC Input Power Cable**







after crimped.










IS06I30010






IS06I30016

# 4.10 Installing the RS485 Communications Cable

#### NOTICE

When routing communications cables, separate communications cables from power cables to prevent communication from being affected.


## **Communication Port Pin Definition**



IS05W00024

Port	Pin	Definition	Pin	Definition	Description
RS485-1 3	1	RS485A IN, RS485 differential signal+	2	RS485A OUT, RS485 differential signal+	Used for cascading inverters or connecting to
	3	RS485B, RS485 differential signal-	4	RS485B, RS485 differential signal-	devices such as the SmartLogger.
PE	5	PE, shielding ground	6	PE, shielding ground	-
RS485-2	7	RS485A, RS485 differential signal+	8	RS485B, RS485 differential signal-	Used for connecting to RS485 slave devices.

### Connecting Communications Cables (4–8 mm Four-Hole Rubber Plug)




#### ☐ NOTE

When using the four-hole rubber plug, block the unused cable hole with a plug, and then tighten the locking cap.

#### Connecting Communications Cables (4–8 mm Two-Hole Rubber Plug)

#### □ NOTE

If three communications cables are to be connected, use the three-hole rubber plug that is bound in the maintenance compartment.



IS06I20050

# 5 Verifying the Installation

- 1. The SUN2000 is installed correctly and securely.
- 2. The DC switches and downstream AC switch are OFF.
- 3. All ground cables are connected securely, without open circuits or short circuits.
- AC output power cables are connected correctly and securely, without open circuits or short circuits.
- 5. DC input power cables are connected correctly and securely, without open circuits or short circuits.
- 6. The RS485 communications cable is connected correctly and securely.
- 7. The maintenance compartment door is closed and the door screws are tightened.
- 8. Unused DC input terminals are sealed.
- 9. Unused USB ports are plugged with watertight caps.

# **6** Powering On the System

### **⚠** WARNING

When LED2 is steady green (meaning that the inverter is grid-tied), do not turn on any DC switch. Otherwise, the inverter may be damaged because the insulation resistance is not detected.

#### NOTICE

- Before turning on the AC switch between the SUN2000 and the power grid, use a multimeter to check that the AC voltage is within the specified range.
- 1. Turn on the AC switch between the SUN2000 and the power grid.
- Set DC SWITCH 1 at the bottom of the SUN2000 chassis to ON. When you hear a click sound, the switch is ON.
- 3. Check the status of LED 1. If it is steady green, set DC SWITCH 2 and DC SWITCH 3 to ON.
- 4. Observe the LED indicators to check the SUN2000 operating status.

#### ∩ NOTE

- Blinking at short intervals (on for 0.2s and then off for 0.2s).
- Blinking at long intervals (on for 1s and then off for 1s).

Display Category	Indicator Status		Description
PV indication	LED1	LED4	-
=[ ]~ (tp) <u>A</u>	Steady green	-	At least one PV string is properly connected, and the DC input voltage of the corresponding MPPT circuit is higher than or equal to 500 V.
LEDI LED4	Blinking green at short intervals	Steady red	An environmental fault occurs at DC side.
	Off	-	The SUN2000 disconnects from all PV strings, or the DC input voltage of each MPPT circuit is less than 500 V.
Grid connection	LED2	LED4	-
indication  =[ ]~ (φ) Λ	Steady green	-	The SUN2000 has connected to the power grid.
O O O O LED2 LED4	Blinking green at short intervals	Steady red	An environmental fault occurs at AC side.
	Off	-	The SUN2000 does not connect to the power grid.
Communications	LED3		-
indication  =[ ]~ (p)	Blinking green a intervals	t short	The SUN2000 receives data over RS485 or MBUS communication.
LED3	Off		The SUN2000 has not received data over RS485 or MBUS communication for 10 seconds.

Display Category	Indicator Status	Description
Alarm/O&M	LED4	-
indication  =〔	Steady red	A warning alarm is generated. If the PV connection indicator and grid connection indicator are both not blinking green fast, replace components or the solar inverter as instructed by the SUN2000 app.
	Blinking red at short intervals	A minor alarm is generated.
	Blinking red at long intervals	A major alarm is generated.
	Steady green	Local maintenance succeeds.
	Blinking green at long intervals	In local maintenance or shuts down over a command.
	Blinking green at short intervals	Local maintenance fails.
	Off	No alarm is generated, and no local maintenance operations are performed.

# SUN2000 APP

#### NOTE

- 1. The SUN2000 app is a mobile phone app that communicates with the solar inverter over a WLAN module, a Bluetooth module, or a USB data cable. As a convenient local monitoring and maintenance platform, it allows for querying alarms, configuring parameters, and performing routine maintenance. The app is named SUN2000.
- 2. Go to Huawei app store (https://appstore.huawei.com), search for SUN2000, and download the app installation package. You can also scan the QR code (https://appgallery.cloud.huawei.com/appdl/C10279542) to download the installation package.
- 3. Connect the WLAN module, Bluetooth module, or USB data cable to the USB port on the solar inverter to ensure that the solar inverter can communicate with the SUN2000 app.



Scan the QR code to download the app (Android).

### Bluetooth Module or WLAN Module Connection



### **USB Data Cable Connection**



#### Login Page

### Select Connection Mode

#### Select User

### Quick Settings










### Function Menu



#### NOTICE

- The screenshots in this document correspond to app version 3.2.00.013 (this app is available only on Android phones currently).
- When the WLAN connection is used, the initial name of the WLAN hotspot is Adapter-WLAN module SN, and the initial password is Changeme.
- The initial password to log in to the app for Common User, Advanced User, and Special User is 00000a.
- Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.
- Set the correct grid code based on the application area and scenario
  of the solar inverter.

# Customer Service Contact

Customer Service Contact						
Region	Country	Service Support Email	Phone			
	France		0080033888888			
	Germany					
	Spain	eu_inverter_support@huawei.com				
Europe	Italy	eu_inverter_support@nuawer.com	0000033000000			
	UK					
	Netherlands					
	Other countries	For details, see solar.huawei.com.				
	Australia	eu_inverter_support@huawei.com	1800046639			
	Turkey	eu_inverter_support@huawei.com	N/A			
	Malaysia		0080021686868 /1800220036			
Asia Pacific	Thailand	apsupport@huawei.com	(+66) 26542662 (charged by local call)			
	mailand		1800290055 (free in Thailand)			
	China	solarservice@huawei.com	400-822-9999			
	Other countries	apsupport@huawei.com	0060-3-21686868			
Japan	Japan	Japan_ESC@ms.huawei.com	0120258367			
India	India	indiaenterprise_TAC@huawei.com	1800 103 8009			
South Korea	South Korea	Japan_ESC@ms.huawei.com	N/A			
North	USA	eu_inverter_support@huawei.com	1-877-948-2934			
America	Canada	eu_inverter_support@huawei.com	1-855-482-9343			
	Mexico		018007703456 /0052-442-4288288			
Latin America	Argentina	la_inverter_support@huawei.com	0-8009993456			
Latin America	Brazil	ta_invertei_support@ndawei.com	0-8005953456			
	Chile		800201866 (only for fixed)			
	Other countries		0052-442-4288288			
	Egypt		08002229000 /0020235353900			
	UAE		08002229000			
Middle East and Africa	South Africa		0800222900			
	Saudi Arabia	eu_inverter_support@huawei.com	8001161177			
	Pakistan		0092512800019			
	Morocco		0800009900			
	Other countries		0020235353900			